

# **MIGHTY MARINER**

## **ENGINE CONTROLS**

### **INSTALLATION MANUAL**

**August 2013**

# ELECTRONIC ENGINE CONTROLS (MM) INSTALLATION INSTRUCTIONS

## Table of Contents

	<u>Page</u>
<b>1. GENERAL INFORMATION.....</b>	<b>1-1</b>
<b>2. SYSTEM COMPONENTS.....</b>	<b>2-1</b>
2.1 THE 6527-S ACTUATOR.....	2-1
2.2 THE 6503 ELECTRONIC CONTROL CARD.....	2-2
2.3 STATION CONTROL HEADS.....	2-4
2.4 SYNCHRONIZER INPUT.....	2-5
2.5 SHAFT BRAKE/NEUTRAL SAFETY SWITCH OUTPUT.....	2-5
2.6 COMPONENT INFORMATION AND PARTS LISTS .....	2-6
<b>3. INSTALLATION.....</b>	<b>3-1</b>
3.1 INSTALLATION HIGHLIGHTS.....	3-1
3.2 ELECTRICAL POWER.....	3-1
3.3 CONTROL HEADS.....	3-2
3.4 ACTUATORS.....	3-2
3.4.1 General.....	3-2
3.4.2 6527-S Electronic Actuator.....	3-3
3.4.3 Throttle Actuator Operation.....	3-4
3.4.4 Clutch Actuator Operation.....	3-4
3.5 THE 6503 CARD.....	3-4
3.6 CABLE INSTALLATION.....	3-6
3.7 SYNCHRONIZER.....	3-7
3.8 SHAFT BRAKE/NEUTRAL SAFETY OUTPUT.....	3-8
3.9 PERIODIC SYSTEM MAINTENANCE.....	3-8
<b>4. OPERATION .....</b>	<b>4-1</b>
4.1 STATION CONTROL HEAD.....	4-1
4.1.1 Station Select.....	4-1
4.1.2 Station Lock.....	4-1

4.1.3	Throttle Override (Engine Warm Up).....	4-1
4.1.4	Synchronizer.....	4-2
<b>5.</b>	<b>INSTALLATION CHECKLIST.....</b>	<b>5-1</b>
5.1	GENERAL.....	5-1
5.2	ACTUATORS.....	5-1
5.3	THE 6503 ELECTRONIC CARD.....	5-2
5.4	CONTROL HEADS.....	5-2
5.5	SYNCHRONIZER.....	5-2
5.6	CABLE INSTALLATION.....	5-2
<b>6.</b>	<b>SYSTEM SETUP AND TEST PROCEDURES.....</b>	<b>6-1</b>
<b>7.</b>	<b>TROUBLESHOOTING.....</b>	<b>7-1</b>
<b>8.</b>	<b>MIGHTY MARINER OPERATING INSTRUCTIONS.....</b>	<b>8-1</b>
<b>9.</b>	<b>PERIODIC SYSTEM MAINTENANCE.....</b>	<b>9-1</b>
<b>10.</b>	<b>CONTROL HEAD CALIBRATION.....</b>	<b>10-1</b>

### **Installation Of Mechanical Pickup For Engine Synchronization And Tachometers**

#### ***THE DRAWINGS***

400929 . . . .	DOUBLE STATION SINGLE ENGINE BLOCK DIAGRAM
400930 . . . .	DOUBLE STATION TWIN ENGINE BLOCK DIAGRAM
400931 . . . .	6505S CONTROL HEAD CONNECTION DIAGRAM
400932 . . . .	6527-S ACTUATOR WIRING DIAGRAM
400933 . . . .	SYNCHRO PICKUP WIRING DIAGRAM
400934 . . . .	NEUTRAL SAFETY SWITCH WIRING DIAGRAM
400935 . . . .	BRAKE SWITCH WIRING DIAGRAM
400936 . . . .	CABLE SCHEDULE
400937 . . . .	DOUBLE STATION SINGLE ENGINE DETAILED WIRING DIAGRAM
400938 . . . .	DOUBLE STATION TWIN ENGINE DETAILED WIRING DIAGRAM
400939 . . . .	DOUBLE STATION TWIN ENGINE BLOCK DIAGRAM 7176 SATELLITE / 6505-2000 CONTROL PANEL
400940 . . . .	DOUBLE STATION TWIN ENGINE BLOCK DIAGRAM 6506 CONTROL HEADS / 6505-2000 CONTROL PANELS

- 400941 . . . . 6505-2000 CONTROL PANEL / 7176 SATELLITE CONNECTION DIAGRAM
- 401045 . . . . 6505 - 2000 CONTROL PANEL / 6506 CONTROL HEADS CONNECTION  
DIAGRAM
- 401126 . . . . 6503 ELECTRONIC INTERFACE CARD CONNECTION DIAGRAM
- 401127 . . . . DOUBLE STATION SINGLE ENGINE ELECTRIC CLUTCH / ELECTRONIC  
THROTTLE BLOCK DIAGRAM
- 401128 . . . . DOUBLE STATION TWIN ENGINE ELECTRIC CLUTCH / ELECTRONIC  
THROTTLE BLOCK DIAGRAM
- 401129 . . . . DOUBLE STATION SINGLE ENGINE ELECTRIC CLUTCH / ELECTRONIC  
THROTTLE DETAILED WIRING DIAGRAM
- 401130 . . . . DOUBLE STATION TWIN ENGINE ELECTRIC CLUTCH / ELECTRONIC  
THROTTLE DETAILED WIRING DIAGRAM
- 401131 . . . . 6503 ELECTRIC CLUTCH DETAILED WIRING DIAGRAM
- 401132 . . . . 6503 ELECTRONIC THROTTLE DETAILED WIRING DIAGRAM AND SET UP  
PROCEDURE

## 1 GENERAL INFORMATION

**Kobelt Electronic Control System** The Kobelt Electronic Control System is a high performance system using the latest development in industrial control technology. This system is capable of controlling single engine and twin engine vessels installations, from one or more control stations.

**Available Features** The available features of the system are as follows:

- Heavy Duty Indoor and Outdoor Control Heads
- Independently Adjustable Shift and Throttle Outputs
- Single or Twin Screw Control
- Engine Warm Up
- Adjustable Shift and Throttle Delays
- Station Lock Out From All Stations
- Selectable Synchronizers
- Shaft Brake/Neutral Safety Switch Outputs
- Up to Four Control Stations
- Self Monitoring
- Throttle Boost
- Mechanical Throttle / Clutch Outputs
- Electronic Throttle / Clutch Outputs

**Setup And Calibration** The system setup and calibration can be maintained through switches and adjustable trimpots.

- The Clutch and Throttle stroke adjustment can be made by adjusting the trimpots on the Actuator.

*See drawing 400932 for the 6527-S Actuator*

**Pay Attention To The Diagrams** The document text provides a general overview of the installation and operation processes. Please pay attention to all of the warnings, product tolerances and limitations discussed in this manual.

**WARNING:** When making the installation, pay close attention to matching the wire colours with the correct terminal numbers, as shown in the diagrams. Any incorrect connection can severely damage the system.

**WARNING:** Always ensure that the electrical power is shut off or disconnected from the Kobelt Electronic Control System before making or adjusting any electrical cable connections.

## 2 SYSTEM COMPONENTS

### 2.1 THE 6527-S ACTUATOR

**Description** The Actuator is the heart of the (Mighty Mariner) Kobelt Electronic Control System. The Actuator monitors all input information from the Control Heads and their associated switch panels, its lever position and the synchronizer inputs. The Actuator also controls and positions its Throttle and its Clutch Levers and communicates with the Control Stations through panel lights and sonalerts

**Purpose** The purpose of an Actuator is to operate the Clutches and Throttles as they all require mechanical positioning.

**Circuitry** The Actuator uses standard Microchip Picprocessor circuitry. All of the system adjustments can be maintained through adjustable trimpots and DIP switches.

**Housing** The circuitry is housed in a heavy duty enclosure.

**WARNING:** **All units are not waterproof and therefore should not be immersed in liquid or washed. This unit should also not be welded, beaten, smashed or dropped.**

**Connections** All connections to the Actuator are hardwired into pluggable connectors on the board. *See drawing 400932.*

**Throttle Output** As the Station Control Head Lever is advanced through the Throttle portion of its travel, the Actuator output increases proportionately to increase the engine speed.

**Clutch Output** For the Clutch Actuator output, the Station Control Head Lever is moved to the forward or reverse position, and the Actuator repositions the Clutch Lever accordingly.

**An Adjustable Synchronizer System** The Synchronizer System is adjustable to designate either the port or starboard Engine as the Main Engine.

**Model 6527-S** The 6527-S Actuator is a two function Actuator with a mechanical disconnect function.

**Working With the CPU** The Actuator repositions its levers by sending electrical signals to its drive motors. The corresponding movements of the levers are fed back to the Actuator card by a gear operated potentiometer to complete the control loop.

**Power Failure:** During a power failure the Actuator levers stays in position.

**Override:** The mechanical override can be used to operate the lever during a power failure.

**Torque** The 6527-S Actuator can deliver 150 inch-pounds of torque.

**Temperature** The operating range of the 6527-S Actuator is -10° to +55° Celsius.

**WARNING:** This unit, while traditionally mounted in or around the engine room, should not be mounted where excessive heat or moisture is present. Nor should it be mounted next to high power devices such as motors, heaters or transmitters.

## 2.2 THE 6503 ELECTRONIC CARD

**Description** The 6503 monitors all input information from the control heads and their associated switch panels, its clutch and throttle positions and the synchronizer inputs. The 6503 also controls and positions its electronic throttle and its electric clutch and communicates with the control stations through panel lights and sonalerts.

**Purpose** The purpose of the 6503 is to operate the clutch solenoid via dry contacts and the electronic throttle via 4 - 20mA, 0 - 5VDC or PWM signal.

**Circuitry** The 6503 uses standard Microchip Picprocessor circuitry. All the system adjustments can be maintained through adjustable trimpots and DIP switches. See drawing 401126

**Housing** The 6503 is housed in a heavy duty enclosure (7173-K box) designed to prevent dust and moisture intrusion.

**WARNING:** The 6503 enclosure is splash proof only and therefore should not be immersed in liquid or washed. This unit should also not be welded, beaten, smashed or dropped.

**Connections** All connections to the 6503 are hard wired into pluggable connectors on the board. *See drawing 401129 / 401130*

**NOTE: Improper wiring connections may result in damage to the 6503**

**Throttle Output** The 6503 has three types of electronic throttle available: 4-20mA, 0-5 VDC and PWM (Pulse Width Modulation).  
*see drawing 401132*

As the Station Control Head lever is advanced through the throttle portion of its travel, the 6503 output increases proportionately to increase the engine speed.

**Clutch Output** For the electric clutch output, the station control head lever is moved to the forward or reverse positions and the 6503 enables the appropriate relay dry contacts to energize the clutch solenoid accordingly.  
*see drawing 401131*

**An Adjustable Synchronizer System** The Synchronizer System is adjustable to designate either the Port or the Starboard engine as the Main Engine.

**Model 6503** The 6503 unit is a two function control card that will provide electronic throttle output and clutch solenoid control.

**Power Failure** During a power failure, the 6503 throttle signal will default to 0 and the clutch relay contact will be de-energized. Therefore, the throttle will default to idle and the clutch to neutral.

**Temperature** The operating range of the 6503 is -10° to +55° Celsius.

**WARNING: This unit, while traditionally mounted in or around the engine room, should not be mounted where excessive heat or moisture is present. Nor should it be mounted next to high power devices such as motors, heaters and transmitters.**

## 2.3 STATION CONTROL HEADS (6505s / 6505-2000)

### Interacting With The Actuator

The Station Control Heads let the operator interact with the Actuator /6503 in the following manner:

- The ship's operator sends instructions to the Actuator / 6503 through control handles and buttons
- The actuator / 6503 sends feedback to the ship's operator through indicator lamps and sonalerts
- The Control Heads connect to the Actuator / 6503 over the distributed control network, through a shielded twisted pair data cable

The Control Heads are manufactured from top quality non-corrosive materials to provide for a long life and an attractive appearance.

### Styles


The Station Control Heads are waterproof from the top side only and capable of withstanding wet weather conditions and can be supplied with a chrome, white, bronze or black epoxy finish.

**The bottom of the Control Head must be protected from the weather.**

### Engaging The Clutches And Throttles

The Control Heads operate through approximately 80 degrees of travel from each side of the centre neutral position. The first 30 degrees per side operate the Clutches and the remaining 50 degrees per side operate the Throttles.

*This graphic shows the side view of a Control Head and the limits of its clutch and throttle regions.*



## 2.4 SYNCHRONIZER INPUT

- Purpose** The Synchronizer is an optional feature which can be added to any new or existing system. The Synchronizer adjusts the speed (shaft RPM) of the Following Engine to match the speed of the Leading Engine.
- Proximity Sensor** The Synchronizer input circuitry uses a proximity sensor mounted on the ship's propeller shafts. The propeller shaft speed is monitored, in preference to the engine speed, to ensure that the propellers are synchronized.

## 2.5 SHAFT BRAKE/NEUTRAL SAFETY SWITCH OUTPUT

- Purpose** The operation of Shaft Brake/Neutral Safety Switch is coordinated with the Kobelt Electronic Control System. The output from this switch indicates that the system is in the neutral position, helping the operator perform safe engine startups and idling.
- Engine Start Interlock** **NOTE:** The Shaft Brake/Neutral Safety Switch can be tied to the engine's starting circuitry. This will prevent the engine from starting unless the Control Head levers are in their neutral positions.



Standard two-engine control head in black finish



Control head in white finish and "E" style handles

## **MODEL 6505S CONTROL HEAD (MIGHTY MARINER SYSTEM)**

This unit has a compact design yet offers all of the features and accuracy of our larger models. Evolved from the popular 6505 model, the 6505S head includes a microprocessor that is used exclusively with the Mighty Mariner system.

The unit can be used

- in combination with the 6527-S clutch/throttle actuator for mechanical control
- in conjunction with Model 6503 Electronic Interface unit to provide electric clutch / electronic throttle outputs


The unit can be used on a single or twin engine configuration. (See examples on the reverse page for different system configurations.)

The unit incorporates the latest technology with provision for switch pad buttons for Station Select, Station Lock, Throttle Override and Synchronizer.

The housing and handles are constructed in all bronze and stainless steel. The standard unit comes in chrome, black epoxy, white or polished bronze finish.

The unit is watertight from the top side and can be used anywhere on board ship. However, the bottom side must be protected from the environment.

For more information about the Mighty Mariner system, please contact Kobelt Manufacturing or visit the website <http://www.kobelt.com>



Picture shows 6527-S actuator with cable (not included in standard unit)

## Model 6527-S Electronic Actuator

Being a modified version of the regular 6527 actuator, the 6527-S actuator is used exclusively in the Kobelt Mighty Mariner System to operate and position lever-actuated mechanisms. Using the latest technology in propulsion control, this actuator unit forms the heart of the Mighty Mariner Control System. The actuator monitors all input information from the control heads and their associated switch panels, its lever position as well as the synchronizer input. This actuator also controls and positions its Throttle and Clutch levers and communicates with the control stations through panel lights and sonalerts. The 6527-S electronic actuators are constructed in bronze and stainless steel, except for the motor and worm. This unit has a high torque of 180 in-lbs.

The basic unit on Model 6527-S comes with manual override and one trim pot per side for stroke adjustment. The actuator does not have an internal resilient link. Hence the stroke must be precisely adjusted to suit the device being controlled.

Note: This actuator is not waterproof and therefore should not be immersed in liquid or washed.






Figure shows typical configuration for Double station Twin engine system

# MODEL 6527-S





## **MODEL 6506 SIDE MOUNT CONTROL**

The 6506 is a side mounting electronic control which can be used for single lever clutch and throttle or any combination of CP propeller and/or trolling valve. This unit is constructed in bronze and stainless steel and the housing is available in chrome and/or black epoxy, (the control handle is always supplied in chrome).



The handle is attached to the control on a 36 tooth spline and can, therefore, be rotated in 10° increments to suit the installation.

The control can be installed in two different ways. An external flush mounting (housing

is exposed) or an internal mounting whereby the housing is behind the control console and only the lever and shaft is exposed. The unit is equipped with friction and detent and can be adjusted to suit customer requirement.

The unit is also available with two potentiometers. The KOBELT computer unit will read both potentiometers but should one fail, the computer would ignore the incorrect signal. This control requires an external headboard. Model 6507 is recommended and can be combined with all other KOBELT control devices.

# MODEL 6506



All dimensions in inches (mm)




**MODEL 6505-2000  
REMOTE SELECTOR PANEL**

The 6505-2000 Remote Selector Panel allows the Walk-About Controller (Model 7176), the Side Mount Controls (Model 6506) or the Model 6555 Control Head to interface with the Kobelt Mighty Mariner System.

This remote unit has all the basic functions available on a 6505S Control station and is suitable for inside or outside installation.

An example of a twin engine, two station system using 7176 is shown as below. You can also get systems for one or two engines, and from one to four stations as well.



**TYPICAL SYSTEM ARRANGEMENT**

(Note: 7176 can be replaced by selected Kobelt Control Head)

### 3 INSTALLATION

#### 3.1 INSTALLATION HIGHLIGHTS

##### **Starting Installation**

1. Engine start/stop must be installed at every station.
2. Kobelt system power breaker must be installed in the wheel house.
3. Wires must be tinned during installation.
4. Free wheeling diodes (protection diodes) must be installed on all inductive devices such as relays and solenoids.
5. Kobelt neutral safety switches must be able to be bypassed to allow starting of the engines if the control system has failed.
6. Clean power sources must be provided.

#### 3.2 ELECTRIC POWER

##### **Power Requirements**

Power requirements for the Kobelt Electronic Control System are as follows:

- 24 Vdc power supply - 10 amps maximum
- Battery charge Regulation - 10% from no load to full load with 10% maximum line variation.

##### **Clean Power is Critical**

A reliable and electrically clean power supply for this system is critical.

- “Main” power should not be taken from an engine starting battery source.
- Power should be taken from the ship’s house battery through a circuit breaker.
- If there is noise on the ship’s house battery system caused by electronics or inverters, it is recommended that a battery dedicated to the electronic engine controls be installed.
- Voltage regulation from the battery charger, inverter or converter should be 10% or better.

##### **Power Switch (Customer Supplied)**

Two sources of power must be provided, a primary source and a secondary source. A three position switch capable of handling the system current must be installed next to the main station, usually the wheelhouse station, to allow the operator to select either the primary power, the secondary power or, in an emergency, the POWER OFF / SYSTEM RESET position.

**Shielding And Ground Connections**

All shielding and ground connections for the Kobelt Electronic Control System are made at the Actuator / 6503 Control Unit.

- The Actuator / 6503 Card is grounded internally, therefore it is best to completely isolate from the ship's grounding.

**3.3 CONTROL HEADS (6505S / 6505-2000)**

**Mounting**

The Control Head circuitry is subject to the same temperature range as the Actuator. The Control Heads should be mounted so they may be lifted up through their mounting holes with their wiring intact.

**DIP Switches**

The DIP Switches on the printed circuit board are used for assigning an address to each Control Head. The Main Station is assigned number 1. The Second Station is assigned number 2. When the system is powered up, the CPU will automatically default to Station 1.

All Control Heads are set to Station #1 when delivered. For a multi station system, the stations addresses must be set during the installation.

*See drawing 400931*

**Options**

All standard Control Heads will come with a four-selection membrane switch with LED indicators. These switches will include options for STATION SELECT, STATION LOCK, THROTTLE OVERRIDE, and SYNCHRONIZER

**3.4 ACTUATORS**

**3.4.1 General**

**Mounting**

All Actuators perform best when they are installed on relatively vibration-free foundation plates.

**WARNING:** Do not mount the Actuator on the engine. All units are not waterproof and therefore should not be immersed in liquid or washed. This unit should also not be welded, beaten, smashed or dropped.

**Temperature**

The operating range of the 6527-S Actuator is -10° to +55° Celsius.

**WARNING:** This unit, while traditionally mounted in or around the engine room, should not be mounted where excessive heat or moisture is present. Nor should it be mounted next to high power devices such as motors, heaters or transmitters.

**Rod Ball End Connections**

If a push/pull cable is selected, it must be a low friction type, such as the Felsted type 40 series, and should be kept as short and straight as possible.

**MUST: Please follow cable manufacturer specifications when installing push/pull cable.**

**Mounting Bracket**

The Actuator's Mounting Bracket should be flat to avoid distortion of the Actuator housing.

**WARNING:** When installing the Actuator, it is mandatory to place a small flat washer under each of the four mounting feet. This is to ensure that there is no distortion of the case when the unit is mounted.

**Electrical Connections**

Connections at the Actuators are made via removable connectors mounted inside the Actuator just inside the removable panel. Cut the cable to the appropriate length.

**WARNING:** Do not coil up excess cable.

**Check The Diagrams**

Check the appropriate wiring diagram for the Actuator. The cable specification and wiring diagrams are at the back of this manual.

**NOTE:** Care must be taken with connections made at the Actuator. Improper wiring connections may result in damage to the Actuator.

FOR ITEMS THAT NEED ACCURATE POSITIONING, A PUSH PULL CABLE IS NOT RECOMMENDED BECAUSE OF THE LOST MOTION IN PUSH PULL CABLES. A SOLID ROD WITH ROD BALL ENDS IS RECOMMENDED.

**3.4.2 6527-S Electronic Actuator**

**Description**

The basic control unit on model 6527-S comes with manual override and one trim pot per side to adjust the stroke. The actuator does not have an internal resilient link . The stroke must, therefore, be adjusted precisely to suit the device being controlled. This unit has a high torque of 150 in.-lbs.

### 3.4.3 Throttle Actuator Operation

**Throttle Movement** The standard throttle actuator operates in a counter clockwise for more RPM and a clockwise rotation for less RPM.

**Electrical Reversal** If this movement is reverse to what is desired, the actuator can be electrically reversed by setting DIP switches.

*See drawing 400932*

### 3.4.4 Clutch Actuator Operation

**Operation** The standard clutch actuator operates in a clockwise rotation for forward and counter clockwise rotation for reverse. The direction can be changed electrically as previously explained.

## 3.5 The 6503 CARD

**Mounting** **Do Not Mount the 6503 on the Engine or the Clutch**

The Electronic circuitry of the 6503 is mounted in a die-cast silicon bronze housing.

**WARNING:** This enclosure is not waterproof and therefore should not be immersed in liquid or washed. This unit should also not be welded, beaten, smashed or dropped.

**Temperature** The operating range of the 6503 is -10° to +55° Celsius.

**WARNING:** This unit, while traditionally mounted in or around the engine room, should not be mounted where excessive heat or moisture is present. Nor should it be mounted next to high power devices such as motors, heaters and transmitters.

**Electrical Connections** All connections to the 6503 are hardwired to removable connectors on the card. Cut the cable to the appropriate length.

**WARNING: Do Not Coil Up Excess Cable**

**Check The Diagrams** Check the appropriate wiring diagram for the 6503. The cable specification and wiring diagrams are at the back of this manual.

**NOTE: Improper wiring connections may result in damage to the 6503 card.**

**Electronic Throttle Operation** The throttle output can be selected to provide a 4 to 20mA, 0 to 5VDC or a PWM signal for electronic governor systems. One output will be selected during the installation.

*See drawing 401132*

**Throttle Movement** The standard throttle produces Minimum signal for idle RPM and Maximum signal for full RPM. For example, 4mA is equal to idle speed and 20 mA is equal to full speed.

**Electrical Reversal** If the electronic signal is reversed to what is desired, it can be electrically reversed by setting DIP switches.

*See drawing 401126*

**NOTE: Reversing the engine signal might cause damage to the clutch. Extreme caution is required.**

**Throttle Cable** The cable used is 3 conductor #18 AWG shielded. The white wire is positive and the black wire is negative. The shield is connected at the 6503 card.

**NOTE: The red wire is not used and must be cut and isolated. The shield must not be connected to the engine side.**

*See drawing 401132*

**Electric Clutch Operation** The 6503 card will provide relay dry contacts output to control the electric solenoid gear drives based on the control head command. The 6503 card will operate the clutch relays which provide a closed contact to operate the gear solenoids.

**Electrical Reversal** If the gear operation is reversed to what is desired, it can be electrically reversed by setting DIP switches.

*See drawing 401126*

**Electric Clutch Cable**            The cable is 3 conductor #18 AWG shielded. The white wire is forward, the red wire is reverse and the black wire is solenoid common

*See drawing 401131*

**NOTE:**            **The shield is not used and must be cut and isolated.  
Protection diodes must be installed to reduce voltage spikes.**

**Protection diodes are supplied.**

### 3.6 CABLE INSTALLATION

**WARNING:** Do not install any cables until after the Actuators or the 6503 card, Control Heads and Synchronizer Inputs have been mounted in their permanent locations.

**Cables**                    All cabling should be firmly fastened, unless housed in conduit. All cables are supplied to the length of 10 meters (33 feet) unless specified.

**WARNING:**    **Cut the cables if they are too long, do not coil them.**

**Power Cable**            The power cable supplied is #12 - 2 conductor. The Red is positive power and the Black (Blk) is negative power.

**Communication Power Cable**    The Communications/Power Cable provides communications and power from the Actuator / the 6503 card to the Station Control Heads.

*See drawing 400936*

**WARNING:** The total length of the communication cable 6525W-C10 must not exceed 40 metres (132 ft).

This Communications/Power Cable is grounded at the Actuator / the 6503. Connect the shield to the Control Headboard terminal but NOT to the case.

**Throttle Cable**            The throttle cable is 3 conductor #18 AWG

*See drawing 401132*

**Synchronizer Cables**

The Synchronizer cable is 7 conductor #18 AWG.

*See drawing 400933*

**Clutch Cable**

The clutch cable is 3 conductor #18 AWG

*See drawing 401131*

**Shaft Brake/  
Neutral Safety  
Cable**

The Shaft Brake/Neutral Safety Cable is 7 conductor #18 AWG.

*See drawing 400934 / 400935*

**Control Head  
Panel Wiring**

All wiring for Control Head panels, between the Control Heads and the push buttons and lights, are factory installed and tested.

**3.7 SYNCHRONIZER**

**Mounting**

The Synchronizer Pickups are mounted near the propeller shafts. These are proximity sensors that send one pulse per shaft revolution to the Actuator.

**Target Size**

The target size for the Pickup should be 2-3" long, 1" wide and about 1/8" thick. Depending on the installation, slightly larger Pickups may be required to make the Synchronizer respond properly.

**Material**

The recommended material is mild steel. If stainless steel is used, the sensing distance of the Pickup may be less.

**Sensing Gaps**

The recommended maximum sensing gap for mild steel is approximately 0.050" (1.4 mm). If stainless steel is used for a target, the maximum sensing gap will be approximately 0.035" (1 mm).

**NOTE:** Please review the instructions that come with the Sensor. The Pickup should be mounted on a vibration-free bracket that allows for adjustment of the sensing gap.

*See drawing 400933*

---

### **3.8 SHAFT BRAKE/NEUTRAL SAFETY OUTPUT**

**Operation**                      The Shaft Brake Output features a set of normally open contacts: These close when the Clutch is in the neutral position. As the Forward or Reverse Clutch is activated, the Brake Relay disconnects and the Brake is deactivated.

**Relays**                              The Neutral Safety Switch Output uses the same relay as the Shaft Brake. The relay is interlocked to Clutch Neutral Position.

### **3.9 PERIODIC SYSTEM MAINTENANCE**

**Inspection**

Inspect system wiring:

- Control heads wiring
- Actuators wiring
- 6503 Electronic card wiring

Inspect and monitor your primary and secondary power sources.

Inspect your push/pull cable connections between actuators and controlled devices. Check cable clamp screws and make sure they are tight.

Perform a system functional test with the engines off and test system operations from all stations and for all functions available (see Kobelt operating instructions)

---

**4. OPERATION****4.1 STATION CONTROL HEAD****4.1.1 Station Select****Purpose**

The STATION SELECT button allows you to transfer engine control from one station to another.

**Selecting** To select a Station, press the STATION SELECT button. After the Station has been selected, the STATION SELECT lamp will illuminate to indicate that the transfer has been completed. This lamp will not turn off until another Station is selected. When a Station is selected, all operating functions are transferred to that Control Head.

**Main Station** When the engine Control System is first activated electrically, the Main Station (Stn. 1 - switch designation) is automatically selected as the Station in control, and the Station Lock function is activated. The control head levers must be set to neutral then press the STATION SELECT button to make the system operational.

**NOTE:** On Power-Up control levers must be set to neutral/idle in order to take control.

#### 4. 1. 2 Station Lock

**Purpose** The Station Lock allows the operator to lock out the other stations. This feature is used to prevent someone from inadvertently switching Station control from the ship's operator at the active Station.

**Engaging** It can be engaged by pressing the STATION LOCK button of the active Station. When it is engaged, the STATION LOCK lamp will illuminate and no other Station can be selected. Pressing the button again will release the Station Lock and the STATION LOCK lamp will turn off.

#### 4. 1. 3 Throttle Override (Engine Warm Up)

**Purpose** Throttle Override (engine warm up) mode allows the ship's operator to move the Throttle independently of the Clutch. This is useful for engine warm up or to increase the engine's speed for external loads (e.g. - hydraulic pump systems). The Neutral Safety Switch will be enabled during engine warm up.

---

**Shifting To Throttle Override** Move the Control Handles to the neutral position, then press the THROTTLE OVERRIDE button. After the button has been pressed, the THROTTLE OVERRIDE lamp will illuminate. The Throttle Override mode prevents the Clutch from moving out of the neutral position.

**Returning To Normal** To select the normal operating mode, return the Control Handles to the neutral position, then press the THROTTLE OVERRIDE button again.

#### 4. 1. 4 Synchronizer

<b>Operation Engagement/ disengagement</b>	The Port and the Starboard levers must be within 10% of each other to allow engagement / disengagement of the Synchronizer option. The Synchronizer is activated by pressing the SYNCHRONIZE button. The Synchronizer circuitry will adjust the position of the Auxiliary Throttle based on the Port/Stbd propeller shaft speeds. When the SYNCHRONIZE light is flashing the Synchronizer is working. When the SYNCHRONIZE light is on solid, the shafts are “in sync” within the dead band.
<b>Sensors</b>	The Synchronizer Sensors, or Pickups, are proximity sensors mounted on the propeller shafts to transmit the speed of the propeller back to the System. The System compares the pulsed inputs from the propeller shafts of the Auxiliary and Main Engines, then adjusts the speed of the Auxiliary Engine to match the Main Engine.
<b>Gear Operation</b>	In the Synchronizer mode the selected Control Head will also operate both gears from the Main Handle.

#### OLD/NEW SOFTWARE REVISIONS:

**NOTE:** The Synchro operation will be disabled in the case of a twin engine system where system components are using different software versions.

**e.g.** An older system that has a newer part fitted with revised software.

CONTROL HEAD OLD REVISION IS 3.7.0  
CONTROL HEAD NEW REVISION IS 4.0

6527-S ACTUATOR OLD REVISION IS 1.4.4  
6527-S ACTUATOR NEW REVISION IS 2.0

---

## 5 INSTALLATION CHECKLIST

### 5.1 GENERAL

- ENGINE EMERGENCY STOPS must be installed at every station
- The primary and secondary power sources must be clean
- The voltage regulation must be within 10% or better of rated battery voltage, e.g. a 24 Volt system should be between 22 and 26 Volts
- A POWER switch (customer supplied) must be installed at the Main Station

- Do not use an engine starting battery as a power source
- Do not install any cables until the Actuators, the 6503, Control Heads and Synchronizer Inputs have been mounted in their permanent locations
- Tin all cables and solder all crimp connectors
- The operating temperature range is -10°C to +55°C
- Double check all voltage polarities (positive/negative), reverse polarities are likely to cause damage

## 5.2 ACTUATORS

- The Actuator's location must be accessible for service
- The Actuator must be installed on a relatively vibration-free plate
- Do not mount the Actuator on the engine
- Do not install Actuator near high-power devices
- This unit is not waterproof and, therefore, must not be mounted where excessive heat or moisture is present and it should not be immersed in liquid or washed
- The Mounting Bracket must be flat
- Place a small flat washer under each of the four mounting feet
- If cables are to be used with the Actuators, rather than solid bars, use only low friction push/pull cables such as the Felsted type 40 series and make them as straight as possible to a maximum of 15 feet in length

**MUST: Please follow cable manufacturer specifications when installing push/pull cable**

- This unit should also not be welded, beaten, smashed or dropped
- Connections are made just inside the removable panel
- Disconnect all cables/remove components prior to welding

---

## 5.3 THE 6503 ELECTRONIC CARD

- The 6503's location must be accessible for service
- The 6503 must be installed on a relatively vibration-free plate
- Do not mount the 6503 on the engine or the clutch
- Do not install the 6503 near high-power devices
- This unit is not waterproof and, therefore, must not be mounted where excessive heat or moisture is present and it should not be immersed in liquid or washed
- This unit should also not be welded, beaten, smashed or dropped

- Connections are made to removable connectors inside the 6503 enclosure
- Disconnect all cables / remove components prior to welding.

#### **5.4 CONTROL HEADS (6505S / 6505-2000)**

- Mount the Control Heads so that you are able to lift them up entirely through their mounting without having to remove their wiring
- The Main Station is assigned address number 1, the Second Station is number 2
- On power up the system will automatically default control to station number 1

#### **5.5 SYNCHRONIZER**

- The Synchronizer Pickups are mounted in close proximity to the propeller shafts
- The Target size for the Pickups should be approximately 2-3" long, 1" wide and about 1/8" thick. These sizes may be increased if necessary
- The recommended material is mild steel
- The recommended maximum sensing gap for mild steel is approximately 0.050"
- If stainless steel is used for a Target, the maximum sensing gap will be approximately 0.035"
- The Pickup must be mounted on a vibration-free bracket that allows for adjustment of the sensing gap
- review the instructions that come with the Sensor

#### **5.6 CABLE INSTALLATION**

- Cut all cables to their appropriate length
- Do not coil up excess cable
- All cabling should be firmly fastened
- Tin all cable ends
- Refer to the diagrams for specific details regarding all cable connections
- Do not run the low-voltage control cables near high-power cables

---

### **6. SYSTEM SETUP AND TEST PROCEDURES**

- Pre-Test Check**
- Make sure that the system is powered down
  - Make sure that all cables are labeled
  - Inspect the system wiring in complete detail, unit by unit

- Disconnect**
- Disconnect the PUSH/PULL cables or mechanical linkage from all Actuators
  - Unplug P6 and P7 from the 6503 electronic interface card
- Power Up**
- Apply power to the system and observe carefully
  - The Main Station sonalert should be beeping and the STATION SELECT lamp should light up
  - If not, power down and inspect all of the wiring again. Then repeat the power up procedure until the system is properly powered up.
- Station Select**
- Once the system is powered up, set the control lever to NEUTRAL/IDLE and then press the STATION SELECT button to acknowledge control
- 6527-S Levers**
- Move the Control Head levers and observe whether the actuators are responding to the lever commands
- 6527-S Throttle/Clutch**
- Determine the Minimum and Maximum Throttle positions as well as the forward and reverse Clutch positions and compare these positions to the Actuator's movement.
  - If you need to reverse an Actuator movement,  
*see drawing 400932*
  - Determine the stroke required for Clutch and Throttle. Make any *coarse* adjustments by moving the cable connection up or down on the Actuator lever. Make any *fine* adjustments by turning the Actuator trim pots to obtain the desired position.
- 6527-S PUSH/PULL Cables**
- With the engine shut down, connect the PUSH/PULL cables to the actuators and fine tune for best results.
- 6503 Levers**
- With a multimeter, move the control levers and verify whether the throttle signal and the clutch relay contacts are responding to the lever commands.
-

**6503  
Throttle/Clutch**

Determine the type of throttle signal as well as the Minimum and Maximum and adjust the appropriate trimpots until designed signal is obtained.

*see drawing 401132*

Note: The 6503 card is already calibrated to produce PWM signal when delivered.

If you need to reverse the throttle or the clutch signal

*see drawing 401126*

**Throttle Delay**

- Once signal calibration is complete and with the engine shut down, connect the clutch and the throttle cables to the 6503 electronic interface.
- Adjust Throttle trimpot clockwise to increase the Throttle delay.  
*The maximum delay is 24 seconds.*

*see drawings 400932 / 401126*

**Neutral Delay**

- Adjust neutral trimpot clockwise to increase the neutral delay.  
*The maximum neutral delay is 24 seconds.*

*see drawings 400932 / 401126*

**Completing The  
Test**

- Once the system has been thoroughly tested and all of the functions are operational, you may now start the engines and test at the idle RPM.
- After everything has been tested and adjusted properly, you may start preparing for a sea trial.

## 7 TROUBLESHOOTING

Symptom	Possible Causes	Remedy
The system is dead	<ul style="list-style-type: none"> <li>The power is off</li> <li>The polarity is reversed on the DC power input</li> </ul>	<ul style="list-style-type: none"> <li>Turn the power on</li> <li>Reverse the connections</li> </ul>
There is a continuous sonalert beep	<ul style="list-style-type: none"> <li>Control Head CPU hangs up</li> </ul>	<ul style="list-style-type: none"> <li>Reset system</li> </ul>
The system is not synchronizing	<ul style="list-style-type: none"> <li>The synchronizer is not set properly</li> <li>There is a problem with the synchronizer wiring</li> <li>Parts are having different software revisions</li> </ul>	<ul style="list-style-type: none"> <li>Adjust the distance between the sensor and the target until the LED starts flashing</li> <li>Check the wiring</li> <li>Software versions need to be matched</li> </ul>
All Actuators are moving erratically	<ul style="list-style-type: none"> <li>There is a ground loop</li> </ul>	<ul style="list-style-type: none"> <li>Check and make sure the cable shields are isolated</li> </ul>
<p><u>One (1) Single Beep</u></p> <p>The Control Head will become disabled</p> <p>All control heads will become disabled</p>	<ul style="list-style-type: none"> <li>The 6505S Control Head DIP switches are incorrectly set</li> <li>The 6527-S Actuator or the 6503 interface card DIP switches are incorrectly set</li> </ul>	<ul style="list-style-type: none"> <li>Check the DIP switches setting of the 6505S Control Head, 6527-S Actuator or the 6503 Interface card</li> </ul>
<u>Two (2) Consecutive Beeps</u>	<ul style="list-style-type: none"> <li>System temperature is above 60°C</li> </ul>	<ul style="list-style-type: none"> <li>Must provide ventilation</li> </ul>

<p><u>Three (3) Consecutive Beeps</u></p> <p>The Actuator will be disabled.</p> <p>If the Clutch Actuator fails, the Throttle will default to idle.</p> <p>If the Throttle Actuator fails, the Clutch will default to Neutral.</p>	<ul style="list-style-type: none"> <li>• The Actuator is jammed</li> <li>• The Actuator motor has failed.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the push pull cable</li> <li>• Check the wiring and the motor</li> </ul>
<p><u>Four (4) or Seven (7) Beeps</u></p> <p>The control head will become disabled.</p> <p>Station Lock will be disabled.</p> <p>Control can be transferred to other stations if equipped</p>	<ul style="list-style-type: none"> <li>• One or more communication wires are missing</li> <li>• One or more terminating resistors are missing</li> </ul>	<ul style="list-style-type: none"> <li>• Check the wiring</li> <li>• Install terminating resistors</li> </ul>
<p><u>Five (5) Consecutive Beeps</u></p> <p>The Actuator will be disabled.</p> <p>If the Throttle Pot fails the Clutch will default to Neutral.</p> <p>If the Clutch Pot fails the Throttle will default to idle.</p>	<ul style="list-style-type: none"> <li>• The Actuator potentiometer is damaged.</li> <li>• One or more of the Pot wires are broken.</li> </ul>	<ul style="list-style-type: none"> <li>• Check the Potentiometer and replace if necessary.</li> </ul>
<p><u>Six (6) Consecutive Beeps</u></p> <p>The Control Head will become disabled</p> <p>Station Lock will be disabled</p> <p>Control can be transferred to other stations if equipped</p>	<ul style="list-style-type: none"> <li>• The Control Head potentiometer is damaged</li> <li>• One or more of the Control Head pot wires are broken</li> </ul>	<ul style="list-style-type: none"> <li>• Check the Potentiometer and replace if necessary</li> </ul>

## 8 MIGHTY MARINER OPERATING INSTRUCTIONS

### On Power Up:

- System default power to station 1, station lock is enabled
- Regardless of control head levers position, the throttle is preset to idle, and the clutch is preset to neutral (mid position)
- Sonalert intermittent beep awaiting for operator to acknowledge control.

### Operating Mode:

- Put levers in neutral position and press station select switch to acknowledge control
- Sonalert is silent
- System is ready to operate the throttle and the clutch according to lever command

### Engine Warm Up

- Press throttle override if engine warm up is desired. Throttle override allows you to control the throttle while the clutch is in neutral position. Levers must be in neutral to enable/disable throttle override.

### Clutch Throttle Operation

- Once in normal mode, advancing the control lever from neutral to full ahead will cause the clutch to move from neutral to ahead position and a proportional throttle signal from idle to full speed
- Moving the lever from neutral to full astern will cause the clutch to move from neutral to astern position and a proportional throttle signal from idle to full speed

### Synchro Option

- Press the synchro switch if engine synchronization is desired. The system will allow one lever to control both clutches and engines synchronized
- Both main and auxiliary control levers must be within 10% difference to allow engagement/disengagement of the synchro option.

### Transferring Control to a Secondary Station

- Disable station lock at the active station
- Match the secondary station levers position to the active station levers position and press station select to transfer control
- Operate clutch/throttle as per station 1 instructions

**Transfer between stations can occur at any control lever positions, therefore, operator attention is required.**

## System Alarm (Sonalert):

A sonalert must be installed at least at the main station. In addition to power up indication, the sonalert will serve the following functions:

**Note: You must stop the vessel and take the immediate action to rectify the problem if any of the following conditions occur:**

- One single beep will occur if the 6505S control head, the 6527-S actuator or the 6503 electronics interface card DIP switches are incorrectly set. One or all control heads will become disabled. Check DIP switches and set correctly.
- Two consecutive beeps will occur if the temperature inside the 6527-S Actuator/the 6503 electronics interface card exceeds 60°C. The system will stay functional for a few more degrees. Once the temperature drops the alarm will disappear.
- Three consecutive beeps will occur if one of the actuator levers is not responding to the control lever command (actuator jam). If the clutch actuator fails the throttle will default to idle. If the throttle actuator fails the clutch will default to neutral. **The actuator will become disabled in either condition.** In the case of a twin engine system, if one actuator fails, the other should remain functional.

**Reset the system power in order to regain control and silence the alarm.**

- Four or seven consecutive beeps will occur if the control head and the actuator or the 6503 are not communicating. **The control head will become disabled**, the system will keep the last position, the system will disable station lock and allow transfer to another station if equipped.
- Five consecutive beeps will occur if the actuator feedback pot has a broken wire. If the clutch actuator pot fails the throttle will default to idle. If the throttle actuator pot fails the clutch actuator will default to neutral. **The actuator become disabled in either condition.** In the case of twin engine system, if one actuator fails the other should remain functional.
- Six consecutive beeps will occur if the control head pot has a broken wire. **The control head will become disabled**, the system will keep the last position, the system will disable station lock and allow transfer to another station if equipped.
- A steady alarm will occur if the control head CPU fails (CPU locks up). **Reset the system power in order to regain control.**

For more details see the troubleshooting section in the installation booklet.

---

## 9 PERIODIC SYSTEM MAINTENANCE

- Inspect system wiring:
  - Control heads wiring
  - Actuators wiring
  - 6503 Electronic interface wiring
- Inspect and monitor your primary and secondary power sources
- Inspect your push/pull cable connections between actuators and controlled devices.
- Perform a system functional test with the engines off and test system operation from all stations and for all functions available.  
(See Kobelt operating instructions)

---

## **10 CONTROL HEAD CALIBRATION**

## **All control Heads Are Calibrated When Delivered**

### **Recalibration Is Required Only When The Headboard or The Pot Has Been Changed In The Field**

*See Drawing 400931 for Jumper J2 Location*

There are three calibration operations required for the Control Head unit. These can all be performed without any external equipment except a 24V power supply connected to terminals 1(V+) and 2(V-) of P1. Calibration can be done with or without other devices connected to the CAN bus as the head produces no CAN bus signals during the calibration routine. In order to enter into the calibration process, a jumper at J2 must be installed. This both enables writes to the internal EEROM as well as causes the software to enter into the calibration routines.

#### **Step No. 1: Pot centering**

With the jumper at J2 installed and both handles in the centre indent, rotate each pot until the STATION SELECT lamp (for the left pot) and the SYNCHRO MODE lamp (for the right pot) come on. This indicates that the pot is electrically centred.

#### **Step No. 2: Minimum offset calibration**

Move both handles to full astern (towards the operator). Then press the STATION SELECT switch. The STATION LOCK lamp will come on to indicate that the offset calibration for the left hand lever was successful. Then press the SYNCHRO MODE switch and the THROTTLE OVERRIDE lamp will come on to indicate that the offset calibration for the right hand lever was successful. At this time both of the inner two lamps will be illuminated.

#### **Step No. 3: Span calibration**

Move both handles to full ahead (away from the operator). As the handles are moved forward, the two inner lamps will turn off. Again press the STATION SELECT switch and confirm that the STATION LOCK lamp lights. Repeat the process with the SYNCHRO MODE switch and check the THROTTLE OVERRIDE lamp. As in step 2 above, both lamps indicate that the respective calibration constants were written correctly to the EEROM.

When the above steps have been completed, remove the jumper at J2 and the head will return to normal operation.


---


## **Installation Of Mechanical Pickup For Engine Synchronization And Tachometers**

Kobelb normally supplies a Pepperl+Fuchs proximity sensor for this purpose. P+F has written some


specification guidelines for this purpose but we are herewith trying to help installation and operation problems in the field.

If a mechanical pickup is installed on a rotating element, it is important to have a sufficient target so that a proximity switch can pick it up. On a fast rotating element the target must be sufficient so that the regular pulse is received. We recommend a target of approximately 2 - 3" long and 1" wide. The target must have a radius that is consistent with the centre of the axis. If the target is not consistent a double pickup might occur. The target must also be installed securely so that it does not become loose and change the intended position. The target should be a minimum of 12mm or 1/2" away from any other solid metal object in order not to receive any interference. The proximity switch must also be installed on a bracket sufficient to withstand the vibration and possibly personnel stepping on it. If the proximity switch comes in contact with the rotating target it will be destroyed. A minimum clearance between the target and the proximity switch is usually approximately 1 -2 mm or 3/32" maximum, the closer the better. It is important, however, that there is no interference between the two items. See sketch below.






CONTRACT		N/A		<b>HOBELT</b> MANUFACTURING COMPANY LIMITED		
CUSTOMER	N/A	DWN	H.A.	BY	MO/YR	TITLE
VESSEL	N/A	CHK	S.C.	26	11/04	DOUBLE STATION SINGLE ENGINE CLUTCH/ THROTTLE ACTUATOR
SCALE		N/A		DRAWING NO		REV
N/A		N/A		A-400929		B
SHEET		1/1				



CONTRACT		<b>HOBELT</b> MANUFACTURING COMPANY LIMITED				
N/A		DWN	DY	MO	YR	TITLE
CUSTOMER		H.A.	26	1	04	DOUBLE STATION TWIN ENGINE CLUTCH/THROTTLE ACTUATOR
N/A		CHK	S.C.	26	1	04
VESSEL		SCALE	SHEET	DRAWING NO	REV	
N/A		N/A	1/1	A-400930	B	



**SINGLE OR TWIN LEVER  
CONFIGURATION:**  
 - SET SW 3 TO OFF POSITION  
 FOR SINGLE ENGINE  
 - SET SW 3 TO ON POSITION  
 FOR TWIN ENGINE



CONTROL HEAD ADDRESS

SW1	SW2
OFF	OFF
ON	OFF
OFF	ON
ON	ON

**NOTE:  
MUST NOT SET TWO STATIONS  
TO THE SAME ADDRESS.**



STATION POSITION  
SELECTOR SWITCH


**CONTROL HEAD CALIBRATION:  
INSERT JUMPER AT J2 AND  
FOLLOW CONTROL HEAD  
CALIBRATION INSTRUCTION  
IN THE INSTALLATION MANUAL.**

 MANUFACTURING COMPANY LIMITED	CONTRACT	N/A	DWN	H.A.	DY MO YR	TITLE
	CUSTOMER	N/A	CHK	S.C.	261104	6505S CONTROL HEAD CONNECTION DIAGRAM
	VESSEL	N/A	SCALE	N/A	SHEET	DRAWING NO
					1/1	A-400931
						REV
						B

TO INCREASE ACTUATOR STROKE TURN TRIMPOT CCW AND VICE VERSA LOCK TRIMPOT WHEN DESIRED POSITION OBTAINED.  
DO NOT ADJUST ACTUATOR NEAR ITS MAX STROKE.  
MUST ADJUST THE STROKE ACCURATELY TO PREVENT THE ACTUATOR FROM ALARMING.

NOTE: MUST SET THE CLUTCH ACTUATOR STROKE ACCURATELY; OTHERWISE, THE THROTTLE ACTUATOR WILL NOT RESPOND. THE CLUTCH MOTOR MUST STOP RUNNING WHEN THE CORRECT STROKE IS OBTAINED. RE-ADJUST STROKE IF MOTOR IS STILL TRYING TO ROTATE (MOTOR HUMMING).

SW 1 FUNCTION		ACTUATOR	FUNCTION
OFF POSITION	PORT ACTUATOR	N/A	PORT/STBD ACTUATOR
ON POSITION	STBD ACTUATOR	THROTTLE ACTUATOR	TRAVEL DIRECTION
	REVERSE	CLUTCH ACTUATOR	TRAVEL DIRECTION
	REVERSE	N/A	SYNCHRONIZER
	AUXILIARY	THROTTLE ACTUATOR	THROTTLE BOOST
	SEE TIMING	THROTTLE ACTUATOR	THROTTLE BOOST
	SEE TIMING		





PULL LEVER UP FOR MANUAL OVERRIDE.

SYSTEM TIMING			
POT	FUNCTION	DELAY	RATE
VR 1	THROTTLE DELAY	0-24 SECONDS	2 TURN/SEC
VR 2	NEUTRAL DELAY	0-24 SECONDS	2 TURN/SEC
THROTTLE BOOST TIMING			
SW 5	THROTTLE BOOST		
OFF	0 %	0 SECONDS	
ON	10 %	2 SECONDS	
OFF	20 %	2 SECONDS	
ON	20 %	3 SECONDS	




NOTE FOR TWIN ENGINE CONFIGURATION: NEUTRAL DELAY AND THROTTLE DELAY MUST BE SET IDENTICAL FOR BOTH ACTUATORS.  
ONE ACTUATOR MUST BE SET TO PORT AND THE OTHER TO STBD.  
DO NOT SET BOTH TO THE SAME SWITCH POSITION (SW 1).  
ONE ACTUATOR MUST BE SET TO MAIN AND THE OTHER TO AUXILIARY.  
DO NOT SET BOTH TO THE SAME SWITCH POSITION (SW 4).

NOTE FOR SINGLE ENGINE CONFIGURATION:  
SW 1 MUST BE SET TO OFF POSITION (PORT ACTUATOR).




CONTRACT	N/A	DWN	H.A.	BY/TWO/VR TITLE	6527-S ACTUATOR WIRING DIAGRAM
CUSTOMER	N/A	CHK	S.C.	160813	160813
VESEL	N/A	SCALE	N/A	SHEET	DRAWING NO
				1/1	B-400932
					REV
					D



**HOBELT** MANUFACTURING COMPANY LIMITED

SYNCHRONIZER CABLE P/N 6525W-B10 7 COND. 18 AWG 10 MTR.		
SYNCH PORT	FUNCTION	WIRE COLOUR
P4-1	+ VDC SYNCH. PULSE COM	BRN
P4-2		BLK
P4-3		BLU




CONTRACT N/A		<b>HOBELT</b> MANUFACTURING COMPANY LIMITED	
CUSTOMER N/A	DWN H.A.	DY MO YR 050204	TITLE SYNCHRO PICK UP WIRING DIAGRAM
VESSEL N/A	CHK S.C.	050204	
	SCALE N/A	SHEET 1/1	DRAWING NO A-400933
			REV B

LED SHOULD FLASH IF SYNCHRO PICKUP AND TARGET ARE INSTALLED PROPERLY.

NEUTRAL SAFETY SWITCH CABLE P/N 6525W-B10 7 COND. 18 AWG 10 MTR.		
NEUTRAL SAFETY SWITCH	FUNCTION	WIRE COLOUR
P5-1	NEUTRAL SWITCH	RED
P5-2		WHT

NEUTRAL SAFETY SWITCH OPERATION:  
 NEUTRAL SAFETY SWITCH WILL ONLY BE CLOSED WHEN SYSTEM IS POWERED UP AND LEVER IS IN NEUTRAL POSITION; THEREFORE, RELAY CONTACTS ARE CLOSED ALLOWING ENGINE TO START. MUST BE ABLE TO BYPASS THE NEUTRAL SAFETY SWITCHES IN ORDER TO START THE ENGINES IF THE CONTROL SYSTEM HAS FAILED.




MUST ADD PROTECTION DIODES TO REDUCE VOLTAGE SPIKES  
 DIODE P/N 1N4005-1N4007

NOTE: RELAY CONTACTS MUST BE ABLE TO HANDLE STARTER SOLENOID CURRENT. RELAY IS CUSTOMER SUPPLIED.

CONTRACT	N/A		<b>HOBELT</b> MANUFACTURING COMPANY LIMITED		
CUSTOMER	DWN	DI	MO	YR	TITLE
N/A	H.A.	05	02	04	NEUTRAL SAFETY SWITCH WIRING DIAGRAM
VESEL	CHK	S.C.	05	02	04
N/A	SCALE	SHEET	1	1	DRAWING NO
	N/A				A-400934
					REV
					B

BRAKE SWITCH CABLE P/N 6525W-B10 7 COND. 18 AWG 10 MTR.		
BRAKE SWITCH	FUNCTION	WIRE COLOUR
P5-1	BRAKE SWITCH	RED
P5-2		WHT

**BRAKE SWITCH OPERATION:**  
 BRAKE SWITCH WILL ONLY BE CLOSED WHEN SYSTEM IS POWERED UP AND CLUTCH IS IN NEUTRAL POSITION; THEREFORE, RELAY CONTACTS ARE CLOSED ALLOWING BRAKE TO BE APPLIED.



MUST ADD PROTECTION DIODES TO REDUCE VOLTAGE SPIKES  
 DIODES P/N 1N4005-1N4007

NOTE: RELAY CONTACTS MUST BE ABLE TO HANDLE BRAKE SOLENOID CURRENT.  
 RELAY IS CUSTOMER SUPPLIED.

CONTRACT N/A		<b>HOBELT</b> MANUFACTURING COMPANY LIMITED	
CUSTOMER N/A	DWN H.A.	DY   MO   YR 05   02   04	TITLE BRAKE SWITCH WIRING DIAGRAM
VESSEL N/A	CHK S.C.	05   02   04	
	SCALE N/A	SHEET 1 / 1	DRAWING NO A-400935
			REV B

# CABLE SCHEDULE – ELECTRONIC ENGINE CONTROLS

## POWER CABLE

P/N 6525W-P10 2 COND. 12 AWG 10 MTR.	
FUNCTION	WIRE COLOUR
VDC + COM	RED BLK

## COMMUNICATION / POWER CABLE

P/N 6525W-C10 2 PAIR 18 AWG SHIELDED 10 MTR.	
FUNCTION	WIRE COLOUR
VDC + VDC - DATA + DATA - SHIELD	WHT 2 BLK 2 WHT 1 BLK 1 SHIELD

## SYNCHRO / NEUTRAL SAFETY / BRAKE CABLE

P/N 6525W-B10 7 COND. 18 AWG 10 MTR.	
FUNCTION	WIRE COLOUR
+ VDC SYNCH PULSE COM NEUT. / BRAKE N/O NEUT. /BRAKE COM NOT USED NOT USED	BRN BLK BLU RED WHT GRN ORG


## ELECTRIC CLUTCH CABLE

P/N 6525W-CT10 3 COND. 18 AWG SHIELDED 10 MTR.	
FUNCTION	WIRE COLOUR
FWD COM REV NOT USED	WHT BLK RED SHIELD

## ELECTRONIC THROTTLE CABLE


P/N 6525W-CT10 3 COND. 18 AWG SHIELDED 10 MTR.	
FUNCTION	WIRE COLOUR
THROTTLE SIGNAL THROTTLE COM NOT USED SHIELD	WHT BLK RED SHIELD

CONTRACT N/A	<b>HOBELT</b> MANUFACTURING COMPANY LIMITED				
CUSTOMER N/A	DWN H.A.	DY 01	MO 12	YR 03	TITLE  CABLE SCHEDULE
	CHK S.C.	01	12	03	
VESSEL N/A	SCALE N/A	SHEET 1/1	DRAWING NO A-400936		REV B




NOTES:  
 THE TOTAL LENGTH OF THE COMMUNICATION CABLE 6525W-C10 MUST NOT EXCEED 40 METRES (132 FT).  
 INSULATE ALL SHIELD WIRES USING SHRINKABLE TUBING.  
 120 OHM TERMINATING RESISTORS MUST BE ADDED TO THE START AND THE END OF THE COMMUNICATION CABLE 6525W-C10.  
 MOUNT TERMINAL BLOCK NEAREST TO CONTROL STATION (5 FT OR MORE).  
 TERMINAL BLOCK IS CUSTOMER SUPPLIED.

CONTRACT	N/A	<b>OMSEL</b> MANUFACTURING COMPANY LIMITED
CUSTOMER	N/A	DOUBLE STATION SINGLE SHUTTLE
DESIGNER	H.A. 281104	REVISIONS CHECKED
SCALE	S.C. 261104	WIRING DIAGRAM
SHEET	N/A	DRAWING NO. B-400937
REV	1/1	B




NOTES:  
 THE TOTAL LENGTH OF THE COMMUNICATION CABLE 622W-B10 MUST NOT EXCEED 40 METRES (132 FT).  
 INSULATE ALL SHIELD WIRES USING SHRINKABLE TUBING.  
 120 OHM TERMINATING RESISTORS MUST BE ADDED TO THE START AND TO THE END OF THE COMMUNICATION CABLE 622W-B10.  
 MOUNT TERMINAL BLOCK NEAREST TO CONTROL STATION.  
 TERMINAL BLOCK IS CUSTOMER SUPPLIED.  
 STBD ACTUATOR IS SET TO MAIN AND PORT ACTUATOR IS SET TO AUXILIARY.

CONTRACT	N/A		MANUFACTURING COMPANY LIMITED			
CUSTOMER	N/A		DWG NO	BY	DATE	TITLE
VESSEL	N/A	H.A.	261104	261104	DOUBLE STATION TWIN ENGINE CLUTCH/THROTTLE ACTUATOR DETAILED WIRING DIAGRAM	
		S.C.	261104			
		SCALE	N/A	SHEET	1/1	DRAWING NO
						REV
						B-400938
						C



CONTRACT		N/A	
CUSTOMER	DWN	DY   MO   YR	TITLE
	H.A.	26   11   04	DOUBLE STATION TWIN ENGINE CLUTCH/THROTTLE ACTUATOR
VESSEL	CHK		
	S.C.	26   11   04	
SCALE		SHEET	DRAWING NO
	N/A	1 / 1	A-400939
			REV
			B


**KOBELT**  
MANUFACTURING  
COMPANY LIMITED



CONTRACT		N/A	
CUSTOMER	OWN	H.A.	DY   MO   YR   TITLE
	GHK	S.C.	26   1   04
VESSEL	SCALE		DRAWING NO
	N/A		A-400940
REV		B	




MANUFACTURING  
COMPANY LIMITED



NOTE: YOU MUST PLUG SATELLITE CABLE INTO 6505-2000 BEFORE TRANSFERRING CONTROL; OTHERWISE, CLUTCH/THROTTLE WILL DEFAULT TO NEUTRAL/IDLE.

**SINGLE OR TWIN LEVER CONFIGURATION:**  
 - SET SW 3 TO OFF POSITION FOR SINGLE ENGINE  
 - SET SW 3 TO ON POSITION FOR TWIN ENGINE



CONTROL HEAD ADDRESS


SW1	SW2	
OFF	OFF	STATION 1
ON	OFF	STATION 2
OFF	ON	STATION 3
ON	ON	STATION 4

NOTE: MUST NOT SET TWO STATIONS TO THE SAME ADDRESS.

**HOBELT** MANUFACTURING COMPANY LIMITED

CONTRACT	N/A	DWN	H.A.	IDY MO/YR	TITLE	REV
CUSTOMER	N/A	CHK	S.C.	080403	6505-2000 CONTROL PANEL/7176 SATELLITE CONNECTION DIAGRAM	A
VESSEL	N/A	SCALE	N/A	SHEET	DRAWING NO	
				1/1	A-400941	

NOTE: AMPHENOL MOUNTING RECEPTACLE IS TIED TO DC COM AND MIGHT CAUSE A LEAK TO GROUND IF MOUNTED ON A METAL HULL.



STATION POSITION SELECTOR SWITCH


**CONTROL HEAD CALIBRATION:**  
 INSERT JUMPER AT J2 AND FOLLOW CONTROL HEAD CALIBRATION INSTRUCTION MANUAL IN THE INSTALLATION MANUAL.

JUMPER

J2


STBD POT	YEL	POT 2
BRN	VREF	-
PORT POT	ORG	POT 1
RED	VREF	+

T-BLOCK MOUNTED ON BOX COVER



HEATSHRINK ALL SHIELD WIRES

**SINGLE OR TWIN LEVER CONFIGURATION:**  
 - SET SW 3 TO OFF POSITION FOR SINGLE ENGINE  
 - SET SW 3 TO ON POSITION FOR TWIN ENGINE




CONTROL HEAD ADDRESS

SW1	SW2		
OFF	OFF	STATION 1	
ON	OFF	STATION 2	
OFF	ON	STATION 3	
ON	ON	STATION 4	


**NOTE:**  
 MUST NOT SET TWO STATIONS TO THE SAME ADDRESS.

**HOBELT**  
 MANUFACTURING COMPANY LIMITED

DWN	H.A.	DY	MO	YR	TITLE
		10	04	03	6505-2000 CONTROL PANEL/6506 CONTROL HEADS CONNECTION DIAGRAM
CHK	S.C.	10	04	03	
SCALE	N/A	SHEET	1/1	DRAWING NO	REV
				A-401045	A



CONTRACT	N/A
CUSTOMER	N/A
VESSEL	N/A




**CONTROL HEAD CALIBRATION:**  
 INSERT JUMPER AT J2 AND FOLLOW CONTROL HEAD CALIBRATION INSTRUCTION IN THE INSTALLATION MANUAL.

HEATSHRINK ALL SHIELD WIRES

SW 1 FUNCTION			
OFF POSITION	ON POSITION	ELECTRONIC CARD	FUNCTION
PORT UNIT NORMAL	STBD UNIT REVERSE	N/A	PORT/STBD UNIT TRAVEL DIRECTION
NORMAL	REVERSE	THROTTLE SIGNAL	TRAVEL DIRECTION
AUXILIARY	MAIN	CLUTCH SIGNAL	SYNCHRONIZER
NOT USED	NOT USED	N/A	NOT USED
NOT USED	NOT USED	NOT USED	NOT USED

J1 & J3 JUMPER FUNCTION	
JUMPER INSTALLED	REMOVED
J1	P7-1 & P7-2 WILL PRODUCE 0-5VDC
J3	120 OHM TERMINATING RESISTOR INSTALLED



SYSTEM TIMING					
POT	FUNCTION	DELAY/% THROTTLE	INCREASE	DECREASE	RATE
VR 5	THROTTLE DELAY SEE NOTE 1	0-24 SECONDS	CW	CCW	1.25 TURN/SEC
VR 2	NEUTRAL DELAY SEE NOTE 1	0-24 SECONDS	CW	CCW	1.25 TURN/SEC
VR 1	THROTTLE BOOST	0%-25% THROTTLE	CW	CCW	1.25 TURN/1% THROTTLE
VR 3	THROTTLE BOOST TIME	0-5 SECONDS	CW	CCW	6 TURN/SEC

- VR 5
- VR 2
- VR 1
- VR 3


ELECTRONIC THROTTLE OUTPUT ADJUSTMENT					
POT	FUNCTION	% THROTTLE SIGNAL	INCREASE	DECREASE	RATE
VR 4	LOW LIMIT ADJUST	0% - 40% THROTTLE SIGNAL	CW	CCW	0.75 TURN/1% THROTTLE
VR 6	HIGH LIMIT ADJUST	60% - 100% THROTTLE SIGNAL	CW	CCW	0.75 TURN/1% THROTTLE

- VR 4
- VR 6


**NOTE 1: MUST SET THROTTLE DELAY FOR 1 SECOND MINIMUM AND NEUTRAL DELAY FOR 1 SECOND MINIMUM.**  
 NOTE FOR TWIN ENGINE CONFIGURATION:  
 NEUTRAL DELAY AND THROTTLE DELAY MUST BE SET IDENTICAL FOR BOTH CARDS.  
 ONE CARD MUST BE SET TO PORT AND THE OTHER TO STBD DO NOT SET BOTH TO THE SAME SWITCH POSITION (SW 1).  
 ONE CARD MUST BE SET TO MAIN AND THE OTHER TO AUXILIARY DO NOT SET BOTH TO THE SAME SWITCH POSITION (SW 4).  
 NOTE FOR SINGLE ENGINE CONFIGURATION:  
 SW 1 MUST BE SET TO OFF POSITION (PORT UNIT).  
 SWITCHES 5 AND 6 ARE NOT BEING USED AND MUST BE SET TO OFF POSITION.  
 NOTE: REVERSING THE ENGINE SIGNAL MIGHT CAUSE DAMAGE TO THE CLUTCH. EXTREME CAUTION IS REQUIRED.

**HOBELT** MANUFACTURING COMPANY LIMITED

CONTRACT	N/A	DRYING TITLE	200412
CUSTOMER	N/A	H.A.	200412
VESEL	N/A	CHK	200412
SCALE	N/A	S.C.	200412
SHEET	1/1	DRAWING NO	B-401126
REV	B		




<b>HOBELT</b>		MANUFACTURING COMPANY LIMITED	
CONTRACT	N/A	DWN	H.A.
CUSTOMER	N/A	CHK	S.C.
VESSEL	N/A	SCALE	N/A
		DY	MO
		YR	
		TITLE	
		DOUBLE STATION SINGLE	
		ENGINE ELECTRIC CLUTCH/	
		ELECTRONIC THROTTLE	
		SHEET	DRAWING NO
		1/1	A-401127
			REV
			B



CONTRACT		N/A	
CUSTOMER		N/A	
VESSEL		N/A	
DWN	BY	MO	YR
H.A.	26	1	04
CHK	TITLE		
S.C.	DOUBLE STATION TWIN ENGINE ELECTRIC CLUTCH/ ELECTRONIC THROTTLE		
SCALE	SHEET	DRAWING NO	REV
N/A	1/1	A-401128	B





MANUFACTURING  
COMPANY LIMITED



NOTE ABOUT CLUTCH SOLENOIDS:  
 TO SWITCH POSITIVE VOLTAGE TO  
 TO GROUND, IF SO REVERSE PROTECTION DIODES.  
 MUST ADD PROTECTION DIODES TO THE  
 PROTECTION DIODE P/N IN4005-IN4007


NOTE ABOUT ELECTRONIC THROTTLE OUTPUT:  
 THIS DRAWING IS SHOWING ALL TYPES OF  
 OUTPUT WILL BE USED BASED ON TYPE OF ENGINE.  
 FOR PWM, 50VDC-50VDC USE WIRE GAUGE 18 AWG OF P7.  
 JUMPER J1 INSTALLED: 0-20VDC OUTPUT.  
 JUMPER J1 REMOVED: 4-20VDC OUTPUT.  
 JUMPER J1 IS N/A FOR PWM OUTPUT.



NOTES:  
 THE TOTAL LENGTH OF THE COMMUNICATION CABLE  
 6525W-C10 MUST NOT EXCEED 40 METRES (132 FT).  
 INSULATE ALL SHIELD WIRES  
 USING SHRINKABLE TUBING.  
 120 OHM TERMINATING RESISTORS MUST  
 BE ADDED TO THE START AND TO THE END  
 OF THE COMMUNICATION CABLE 6525W-C10.  
 INSTALLING J5 JUMPER AT THE 650J CARD  
 CHANGES THE CONNECTIONS AT CONNECTOR P2.  
 THEREFORE NO EXTERNAL RESISTOR IS REQUIRED AT P2.  
 MOUNT TERMINAL BLOCK NEAREST TO CONTROL STATION  
 (1.5 FT OR LESS).  
 TERMINAL BLOCK IS CUSTOMER SUPPLIED.

CONTRACT	N/A	DWG	DT/MT/RT	TITLE
CUSTOMER	N/A	H.A.	261104	DOUBLE STATION SINGLE ENGINE ELECTRIC CLUTCH/
VESSEL	N/A	G.K.	261104	DETAILED WIRING DIAGRAM
SCALE	N/A	S.C.	1/1	SHEET
REV	N/A	DRAWING NO	B-401129	REV





NOTE ABOUT ELECTRONIC THROTTLE OUTPUT:  
 THIS DRAWING IS SHOWING ALL TYPES OF THROTTLE OUTPUT. NORMALLY ONLY ONE OUTPUT WILL BE USED BASED ON TYPE OF ENGINE. FOR PWM SIGNAL USE TERMINALS 3,4,5 OF P7. FOR 4-20mA/0-5VDC USE TERMINALS 1,2,5 OF P7. JUMPER J1 INSTALLED: 0-5VDC OUTPUT. JUMPER J1 REMOVED: 4-20mA OUTPUT. JUMPER J1 IS N/A FOR PWM OUTPUT.

NOTES:  
 THE TOTAL LENGTH OF THE COMMUNICATION CABLE 6525W-C10 MUST NOT EXCEED 40 METRES (132 FT). INSULATE ALL SHIELD WIRES USING SPRINKABLE TUBING. 120 OHM TERMINATING RESISTORS MUST BE ADDED TO THE START AND TO THE END OF THE COMMUNICATION CABLE 6525W-C10. INSTALLING J3 JUMPER AT THE PORT 6503 CARD WILL INTERNALLY CONNECT A 120 OHM TERMINATING RESISTOR TO EACH OF THE COMMUNICATION CABLES. THEREFORE, NO EXTERNAL RESISTOR IS REQUIRED AT P2. MOUNT TERMINAL BLOCK NEAREST TO CONTROL STATION (1.5 FT. MINIMUM). (IF LESS THAN 1.5 FT. TERMINAL BLOCK IS CUSTOMER SUPPLIED. STED CARD IS SET TO MAIN AND PORT CARD IS SET TO AUXILIARY.)

NOTE ABOUT CLUTCH SOLENOIDS:  
 CLUTCH SOLENOIDS COULD BE WIRED TO SWITCH POSITIVE INSTEAD OF SWITCHING TO GROUND IF SO REVERSE PROTECTION DIODES. MUST ADD PROTECTION DIODES TO THE SOLENOID COILS TO REDUCE VOLTAGE SPIKES. PROTECTION DIODE P/N 1N4005-1N4007.


STATION 2  
 SEE DWG 400931  
 65055

STATION 1  
 SEE DWG 400931  
 65055







CONTRACT	N/A	MANUFACTURING COMPANY LIMITED
CUSTOMER	N/A	DOUBLE STATION TWIN ENGINE ELECTRIC CLUTCH/
VESSEL	N/A	DETAYLED WIRING DIAGRAM
SCALE	N/A	DRAWING NO
REV	1/1	B-401130

ELECTRIC CLUTCH CABLE P/N 6525W-CT10 3 COND. 18 AWG 10 MTR.	
6503 ELECTRIC CLUTCH	FUNCTION FORWARD SIGNAL COM REVERSE SIGNAL NOT USED
P6-1	WIRE COLOUR WHT
P6-2	BLK
P6-3	RED
	SHIELD

NOTE ABOUT CLUTCH SOLENOIDS:  
CLUTCH SOLENOIDS COULD BE WIRED  
TO SWITCH POSITIVE INSTEAD OF SWITCHING  
TO GROUND, IF SO REVERSE PROTECTION  
DIODES.  
MUST ADD PROTECTION DIODES TO THE  
SOLENOID COILS TO REDUCE VOLTAGE SPIKES.  
PROTECTION DIODE P/N 1N4005-1N4007



CONTRACT N/A	<b>HOBELT</b> MANUFACTURING COMPANY LIMITED	
CUSTOMER N/A	DWN H.A.	DY MO YR 271103
VESSEL N/A	CHK S.C.	TITLE 6503 ELECTRIC CLUTCH OUTPUT PORT DETAILED WIRING DIAGRAM
	SCALE N/A	SHEET 1/1
		DRAWING NO A-401131
		REV A



**CABLE INFORMATION & NOTES**

ELECTRONIC THROTTLE CABLE P/N 6525W-CT10 3 COND. 18 AWG 10 MTR. SHIELD	
6503 ELECTRONIC SIGNAL	FUNCTION
P7-1	0-5VDC/4-20mA COM
P7-2	PRIMARY THROTTLE (PWM)
P7-3	THROTTLE COM
P7-4	SHIELD
P7-5	SHIELD

**NOTES:**

- SEE DRAWING 401128 FOR MORE 6503 CARD DETAILS
- ENGINE MUST BE OFF DURING SYSTEM CALIBRATION
- THE 6503 IS ALREADY PRESET TO PRODUCE PWM SIGNAL
- SIGNAL CALIBRATION IS REQUIRED IF 4-20mA OR 0-5VDC SIGNAL IS DESIRED.

CONTRACT	N/A	<b>HOBEL</b> MANUFACTURING COMPANY LIMITED	
CUSTOMER	N/A		
DATE	28/11/03		
BY	S.C.		
SCALE	N/A	DRAWING NO	B-401132
REV	1/1	REV	A