


# ***KOBELT***

## **KP16 & KP18 Hydraulic Thrusters**

*Owner's Manual*



February 2022

Kobelt Manufacturing Co. Ltd

## This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and extend across the width of the page. There are no margins, text, or other markings on the paper.

RECORD DATA BEFORE INSTALLATION FOR FUTURE REFERENCE	
Model #:	
Serial #:	
Date of purchase:	
Date of installation:	
Motor brand and part #:	

# TABLE OF CONTENTS

<b>1</b>	<b>Introduction .....</b>	<b>3</b>
1.1	Contact .....	3
1.2	Safety.....	3
<b>2</b>	<b>Product Description .....</b>	<b>5</b>
2.1	Overview.....	5
2.2	Model Code Key.....	6
2.3	Technical Data .....	6
2.4	Parts.....	7
<b>3</b>	<b>Installation and Location Selection .....</b>	<b>8</b>
3.1	Tunnel Thruster Location and Installation .....	8
3.2	Bolt-On Thruster Location and Installation .....	15
3.3	Lubricating Oil System .....	19
<b>4</b>	<b>Maintenance and Service.....</b>	<b>20</b>
4.1	Preventative Maintenance .....	20
4.2	Recommended Spare Parts.....	20
4.3	Propeller Installation and Removal.....	21
4.4	Bolt-On Thruster Tube Removal and Installation .....	22
4.5	Setting Coupling Distance .....	24
4.6	Bearing Cap Removal & Oil Drain.....	24
4.7	Oil Changes .....	25
4.8	Shaft Seal Replacement .....	26
<b>5</b>	<b>Hydraulics .....</b>	<b>27</b>
<b>6</b>	<b>Parts Lists .....</b>	<b>29</b>
6.1	Tunnel Thruster Top-Level Assembly .....	29
6.2	Bolt-On Thruster Top-Level Assembly.....	33
6.3	Leg Subassembly.....	37
6.4	Shaft Subassembly.....	40
6.5	Accessories .....	41
6.6	Parts Lists Notes .....	42
<b>7</b>	<b>Technical Drawings.....</b>	<b>44</b>
7.1	Tunnel Thrusters.....	44
7.2	Bolt-On Thrusters .....	45
<b>8</b>	<b>Warranty.....</b>	<b>46</b>

# 1 INTRODUCTION

## 1.1 CONTACT

**Kobelco Manufacturing Co. Ltd.**  
8238 129th Street  
Surrey, British Columbia  
Canada, V3W 0A6

Sales Tel: +1-604-572-3935  
Fax: +1-604-590-8313  
Email: [sales@kobelt.com](mailto:sales@kobelt.com)  
Website: [www.kobelt.com](http://www.kobelt.com)




This document is intended to clearly present comprehensive product data and provide technical information to assist the end user in design applications. Kobelt reserves the right, without notice, to change the design, or construction, of any products and to discontinue or limit distribution of any products. Kobelt also reserves the right to change, or update, without notice, any technical information contained within this document.

Kobelco recommends that customers visit our website to check for updates to this Manual. Once a product has been selected for use, it should be tested by the user to ensure proper function in all possible applications. For further instructions, please contact our distributors or visit our website.

## 1.2 SAFETY

### 1.2.1 Safety Alerts

Throughout this manual, the following symbols, and their accompanying explanation, are used to alert the user to special instructions concerning a service or operation that may be hazardous if performed incorrectly or carelessly. The associated risk levels are stated below.



 <b>DANGER</b>	This symbol indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
 <b>WARNING</b>	This symbol indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
 <b>CAUTION</b>	This symbol indicates a hazardous situation, which if not avoided, could result in minor or moderate injury.
<b>NOTICE</b>	This symbol informs the reader of events not related to personal injury but which there is a risk of damage to property or equipment.
<b>SAFETY INSTRUCTIONS</b>	This symbol informs the reader of safety-related instructions or procedures.

### 1.2.2 Notice to Installer

Disregarding the following safety measures can result in an accident causing severe injury to personnel and damage to material assets.

- Only use the product as directed in this manual.
- Never put the product into service if there is evidence of visible damage.
- Never put the product into service before fully completing installation and commissioning.
- Do not carry out any modifications to the product.
- Only use authentic Kobelt spare parts.
- Observe all local regulations, directives and laws during the installation of this product.
- All installation, commissioning, and maintenance work must only be conducted by qualified personnel. (For the purpose of this manual, qualified personnel are persons who are familiar with the assembly, installation, commissioning, and operation of the product and who have the qualifications necessary for their occupation.)
- Observe all specifications in this manual. If these guidelines are not followed and damage occurs, the warranty will be voided.

### 1.2.3 Product Hazards

 <b>WARNING</b>	The rotating components of the thruster can generate forces that can cause pinch or crush injuries. Keep body parts clear of the thruster when it is operating. Lock out any power sources before working on the thruster.
 <b>WARNING</b>	Exercise safety precautions pertaining to hydraulics including: <ul style="list-style-type: none"> <li>• Wearing safety glasses.</li> <li>• Exhausting pressure and locking out the pressure source.</li> <li>• Being qualified to work on hydraulics.</li> </ul>
<b>NOTICE</b>	On standard thruster installations, the mounting saddle installation to the tube should be considered permanent once installed and should not be removed. The leg and propeller assemblies can simply be detached from the saddle when service is required. This ensures the saddle stays sealed and correctly aligned eliminating the need for propeller realignment or saddle resealing.
<b>NOTICE</b>	On transom mounted thruster installations, the mounting plate and saddle installation should be considered permanent once installed and should not be removed. The thruster leg assembly and tube can simply be detached from the rest of the installation when service is needed allowing the mounting plate installation to remain sealed.
<b>NOTICE</b>	To help prevent corrosion, it is strongly recommended to connect the thruster to the vessel's existing bonding system. Consult a marine electrical specialist for advice regarding modifying your vessel's bonding system.

## 2 PRODUCT DESCRIPTION

### 2.1 OVERVIEW

The figure below shows a typical tunnel thruster with all of its major components identified. Thrusters are meant to assist in docking, station keeping and maneuvering in tight spaces and are usually installed to an athwartships tunnel that goes through the vessel's hull (tunnel thrusters). Thrusters are also offered in bolt-on versions which do not attach to a tunnel but instead mount externally to the transom of a vessel. Thrusters are powered by a hydraulic motor which is mounted to the thruster saddle. The direction of thrust can be changed by reversing the direction of oil flow to the hydraulic motor. All thrusters are available in aluminum or bronze versions.





Figure 1 – Names of thruster components

2.2 MODEL CODE KEY



2.3 TECHNICAL DATA

Your authorized Kobelt distributor typically will also sell you a hydraulic motor that is most compatible with your vessel’s existing hydraulic system. Given that there is no “standard” motor, pressure and flow requirements do not depend solely on the thruster model used and will vary from installation to installation. Table 1 below provides examples of possible operating parameters for typical installations. Note that operating parameters are also affected by the vessel’s hull and tunnel geometry.

Table 1 – Hydraulic motor operating specifications

Model	Flow	Pressure	Power
KP 16	32 gpm	2,600 psi	49 hp
	121 lpm	179 bar	36 kW
KP 16 HD	45 gpm	2,500 psi	66 hp
	170 lpm	172 bar	49 kW
KP 18	45 gpm	2,400 psi	63 hp
	170 lpm	165 bar	47 kW
KP 18 HD	50 gpm	3,000 psi	87 hp
	189 lpm	207 bar	65 kW

## 2.4 PARTS

Detailed parts lists can be found in section 6 of this manual. You should find the following items when you receive your Keypower thruster:

- A completely assembled thruster which consists of
  - Hydraulic motor (sold separately)<sup>1</sup>
  - Saddle
  - Leg subassembly
  - Propeller
  - Prop nut
  - Mounting plate (bolt-on transom thrusters only)
  - Fibreglass tube (bolt-on transom thrusters only)
- Prop puller tool
- Header tank and its mounting hardware
- Installation bolt kit (tunnel thrusters only)
- Template for thruster tube cut (tunnel thrusters only)
- Backing plate (bolt-on transom thrusters only)
- This manual

Kobelt can supply fibreglass, steel and aluminum tubes for your thruster if needed. If supplying your own tube, be aware that the wall thickness must be correct for proper alignment of the thruster; you may be required to build up to the thruster saddle for thinner tubes. Refer to the table below for the required tube dimensions of each thruster size.

*Table 2 – Thruster tube dimensions*

Model	Tube ID [inches]	Wall Thickness [inches]
KP 16 / KP 16 HD	16	1/2
KP 18 / KP 18 HD	18	5/8

<sup>1</sup> Prior to commencing thruster installation, you should note down the make and model of the motor that has been supplied with your thruster on the space provided on page 1.



## 3 INSTALLATION AND LOCATION SELECTION

This section has been prepared to assist the owner and the installer in understanding the installation of the thruster to the vessel. All work should be performed by a professional who is competent in marine mechanical installations.

### NOTICE

Installation of the thruster involves cutting into the hull of the vessel and improper material use or workmanship can result in property damage, and/or a loss of performance.

Care should be taken when selecting a location for the thruster installation as it can greatly affect the performance of the thruster. A thruster is a low-pressure axial pump whose performance is sensitive to the interference to the influx of water to the propeller and the pressure distribution outside of the vessel's hull. Additionally, the thruster installation can increase the drag of the vessel if due care is not taken in selecting its location. For the reasons mentioned, special consideration must be given so that a hydrodynamically favourable and economically sensible installation is achieved. If the guidelines in this manual are not taken into consideration, then a loss of thrust should be expected. Best results can be achieved by consulting with a naval architect familiar with the vessel.

### 3.1 TUNNEL THRUSTER LOCATION AND INSTALLATION

This section describes the installation of the tunnel and thruster to your vessel. You can either:

- Install the tube to the hull first, and then install the thruster to the tube.
- Make the leg cut out and mounting holes first (steps 1 to 6 in section 3.1.4 on page 13), install the tube to the vessel, then complete the installation by sealing the thruster to the tube (remaining steps in section 3.1.4).

Note that the following instructions are for tunnel installations only (installing to an athwartships tunnel through the vessel's hull), see section 3.2 on page 15 for bolt-on thruster installation instructions.

#### 3.1.1 Locating the Thruster on Your Vessel

Consider the following when selecting a location to install the thruster:

- Locating the thruster as far forward in the vessel will maximize its effectiveness.
- The propeller's midline should be located as close to the centreline of the vessel as possible. The provided cutting template has the propeller midline location marked on it which will allow you to accurately locate the propeller midline.
- Account for the space the saddle, motor, and any hydraulic fittings and hoses will take up within the vessel. See Figure 21 on page 44 for the thruster's dimensions.
- The thruster can be installed so that the drive components are above the tube, horizontal to the tube or at any angle in between.
- No parts of the thruster are to extend outside of the hull.
- The tunnel's length, vertical positioning, and opening shape all greatly affect thruster performance. Refer to Figure 2 on page 9 and accompanying Table 3 for definitions of these parameters and their recommended values.




Figure 2 – Thruster tunnel location parameters that affect performance

Table 3 – Recommendations for thruster tunnel location

Dimension	Recommendation	Consequence if recommendation not met
<b>T</b>	<ul style="list-style-type: none"> <li><math>T \geq D^*</math></li> <li><math>T = 1.5D</math> is best</li> </ul>	<ul style="list-style-type: none"> <li>Insufficient depth can cause air suction which reduces thrust, increases noise and vibration, and can damage the thruster.</li> <li>Note that excessive depth can be inefficient and cause excessive roll of the vessel during thruster operation.</li> </ul>
<b>L</b>	<ul style="list-style-type: none"> <li><math>L \geq 2D</math></li> <li><math>L \leq 6D</math></li> </ul>	<ul style="list-style-type: none"> <li>Insufficient length does not allow the flow to calm down thus decreasing thrust.</li> <li>Excessive length increases flow resistance thus decreasing thrust.</li> </ul>
<b>K</b>	<ul style="list-style-type: none"> <li>If <math>L &lt; 3D</math>, then <math>K \geq D/2</math></li> <li>If <math>L \geq 3D</math>, then <math>K \geq D/4</math></li> </ul>	<ul style="list-style-type: none"> <li>Circular currents can develop below the hull of the ship which decrease thrust.</li> </ul>
<b>a</b>	<ul style="list-style-type: none"> <li>Close to <math>90^\circ</math> as possible</li> </ul>	<ul style="list-style-type: none"> <li>Greater hull inclination results in decreased thrust (for this reason a bulbous bow makes an excellent location for a thruster).</li> </ul>
<b>S</b>	<ul style="list-style-type: none"> <li><math>S \geq 0.10D</math></li> <li><math>S \leq 0.15D</math></li> <li>Cone (good) or radius (better)</li> </ul>	<ul style="list-style-type: none"> <li>Insufficient tunnel fairing causes incoming water to be excessively turbulent decreasing thrust.</li> <li>Excessive fairing will increase the hull drag during normal ahead travel.</li> </ul>

\*Note this dimension applies to the *lightest* waterline. Vessels used in open seas must also consider the effects of pitch, roll and wave action on the submersion of the thruster.

### 3.1.2 Protective Grid

Grids are often fitted to thruster installations with the intent of reducing the drag created by the tunnel opening and to prevent the ingress of objects that could potentially damage the thruster. Kobelt recommends consulting with a naval architect to design the protective grid as the optimum design will depend greatly on the shape and operating conditions of your vessel.

## NOTICE

It is recommended to consult with a naval architect/shipyard to design a protective grid. The optimum grid design depends highly on the specifics of your vessel. A poorly designed grid can cause a large decrease in thruster performance.

If it is not possible to consult with a professional regarding the design of a protective grid but it is still desired to have one, follow the instructions below for a general installation that will achieve satisfactory performance at best.

- The grid should be made up of two to four equally spaced parallel bars which are interconnected by one perpendicular bar across the centre of the parallel bars (see Figure 4 below).
- Elliptical bars will result in the best performance. Rectangular bars should also result in acceptable performance if cost is a concern. Round and square bars are not recommended under any circumstances as they generally perform poorly.
- The bars should not cover more than 10% of the tunnel area.
- Mount the grid behind the induction cone/radius (see Figure 3 below).




Figure 3 – Recommend location of protective grid

- Angle the parallel bars so they are aligned perpendicular to the flow of water over the hull of the bow in the location of the tunnel (left image in Figure 4). The flow of the water of the hull is typically determined from model tests. If the direction of the flow is not known, mounting the bars 15° relative to the waterline *could* result in *satisfactory* performance (right image in Figure 4).



Figure 4 – Orientation of protective grid relative to vessel

### 3.1.3 Installation of Fibreglass Thruster Tubes

This section has been prepared to assist the owner and installer in understanding the installation of fibreglass thruster tubes. All work should be done by a professional who is competent in marine mechanical installations. The tube can be installed after or before the leg cut-outs and mounting holes have been made (steps 1 to 6 in section 3.1.4 on page 13 instruct how to make the cut out and mounting holes).

1. Determine a suitable location for the thruster using the guidelines described in *3.1.1 Locating the Thruster on Your Vessel*.
2. Cut a hole in the hull large enough in diameter to allow for a fairing with a minimum radius as specified in Table 3 on page 9.
3. Cut the tube to length so that it fits in between the holes cut in the hull. Allow for a gap between the tube and hull for the radius. If the mounting holes and cut-out have already been made, then you must also ensure that the tube length is cut so that the propeller midline is centred as much as possible athwartships.
4. Move the tube to the desired position in the vessel and fix it in place.
5. Fibreglass the tube in place. Fibreglass must cover the entirety of the tube exterior except in the area the saddle will mount to. Fibreglass thickness should be in accordance to the applicable marine standards for the vessel. Refer to Figure 5 on page 12 for an example of a fibreglass tunnel installation.

## NOTICE

Under no circumstances should fibreglass be applied to the area of the tube which contacts the underside of the saddle. Any additional thickness in the area of the flange will adversely affect the fit of the thruster assembly.





Figure 5 – Thruster tube fibreglassing example

### 3.1.4 Installing the Thruster to the Tube

This section has been prepared to assist the owner and installer in understanding the installation of the thruster to the tube. All work should be performed by a professional who is competent in marine mechanical installations. The thruster can be installed to the tube before or after the tube has been installed to the hull.

1. Use the provided cutting template to cut the required opening in the tube<sup>2</sup>. Note that the bolt holes are not shown on the cutting template. These are added later.
2. Remove the propeller as directed by the instructions in section 4.3 *Propeller Installation and Removal* on page 21 of this manual. Also, refer to that section whenever these steps instruct you to reinstall the propeller.
3. Insert the thruster leg through the opening in the tube as shown below.



4. Reinstall the propeller and trial-fit the thruster. Check for tip clearance by using wooden shims between the propeller blades and inner surface of the tube to centre and position the thruster.
  - Variations in tube thickness can cause the propeller to sit too close to one side. It may be necessary to shim or grind the area on the tube where the saddle sits.
5. With the thruster properly aligned, match drill six 1/2" holes with the existing saddle mounting holes through the tube.
6. Remove the propeller from the thruster assembly and remove the thruster assembly from the tube, then:
  - Metal tubes: File the holes in the tube so that they are square-shaped.
  - Fibreglass tubes: Increase the size of the holes in the tube to 17/32".

---


<sup>2</sup> The cutting template can also be downloaded from the [KP16 product page](http://www.kobelt.com) at [www.kobelt.com](http://www.kobelt.com).

7. At this point it is recommended to apply a marine barrier coat and antifouling paint to the thruster tunnel. The following sub-steps will guide you through that process:
  1. Obtain marine barrier epoxy and antifouling paint that is appropriate for the operating environment of the vessel.
  2. Apply the epoxy barrier coat to the inner diameter of the thruster tube. Refer to the information provided by the epoxy manufacturer for application procedures, recommended thickness, and drying time.
  3. Apply the antifouling paint to the inner diameter of the thruster tube. Refer to the information provided by the paint manufacturer for application procedures, recommended thickness, and drying time.

**NOTICE**

Paint and coatings can be applied to the thruster as well, however, **nothing should be applied to the zinc anode or the surface on which the anode mounts to.**

8. Apply a generous amount of 3M 5200 marine adhesive sealant (standard or fast cure) on the surfaces where the bottom of the saddle and tube contact each other and the 6x mounting holes. Reinsert the thruster assembly into the tube. Apply a liberal amount of 3M 5200 to the provided mounting bolt kit fasteners and secure the thruster to the tube (hand tight). Make sure to follow any gap size limits stated in the instructions that are provided with the sealant. See image below for fastener orientation.



9. Reinstall the propeller. Check for tip clearance by using wooden shims between the propeller blades and the inner surface of the tube to centre and position the thruster.
10. Tighten the 6 mounting nuts to 5-10 lbf-ft and remove the shims. Allow for the sealant to cure (refer to the instructions provided with the sealant for cure time).
11. After the sealant has cured, torque the 6 nuts to 50 lbf-ft. The mechanical installation of the thruster to the tube is now complete. Note down the make and model of the hydraulic motor on page 1 of this manual for future reference if you have not done so already.

## 3.2 BOLT-ON THRUSTER LOCATION AND INSTALLATION

### 3.2.1 Locating the Bolt-On Thruster on your Vessel

Consider the following when selecting a location to install the thruster:

- The tube should be centred about the centreline of the vessel as much as possible.<sup>3</sup>
- Account for the space the saddle, motor, and any hydraulic fittings and hoses will take up within the vessel. See Figure 22 on page 45 for the thruster's dimensions.
- Insufficient submersion can cause air to be sucked into the thruster tube which can result in excessive noise and vibration, decreased thrust, and damage to the thruster. The top of the tube should be at least one tunnel diameter deep from the *lightest* waterline (i.e., T should be greater than D in Figure 6). For vessels operating in open seas an allowance for pitch, roll, and wave action should be added to the minimum submersion recommendation.
- Submerging the thruster too deep to where the tube extends past the bottom edge of the transom is permissible but can cause increased drag during regular ahead travel.
- The transom needs to be flat in the location the thruster mounting plate will be fixed to. Curved surfaces may cause the seal between the mounting plate and hull to fail causing an ingress of water into the vessel.

If you find it challenging to fit the standard tube offering to your vessel, please contact Kobelt Manufacturing and we will try to come up with a custom solution that will work for you.




Figure 6 – Bolt-on thruster submersion recommendation

<sup>3</sup> If having to choose between sufficient submersion or centering the tube athwartships, the location that ensures sufficient submersion should be used.



### 3.2.2 Tube Preparation

It is recommended to apply a marine barrier coat and antifouling paint to the tube before installing the thruster to the transom. The steps below will guide you through that process.

#### NOTICE

Paint and coatings can be applied to the thruster as well, however, **nothing should be applied to the zinc anode or the surface on which the anode mounts to.**

1. Remove the tube as described in section 4.4 on page 22.
2. Obtain marine barrier epoxy and antifouling paint that is appropriate for the operating environment of the vessel.
3. Apply the epoxy barrier coat to the entirety of the thruster tube. Refer to the information provided by the epoxy manufacturer for application procedures, recommended thickness, and drying time.
4. Apply the antifouling paint to the entirety of the thruster tube. Refer to the information provided by the paint manufacturer for application procedures, recommended thickness, and drying time.
5. Reinstall the tube as described in section 4.4 on page 22.

### 3.2.3 Cutting the Transom

This section instructs how to install transom-mounted thrusters. All work should be done by a professional who is competent in marine mechanical installations. It is recommended to prep the tube as per instructions in the previous section prior to installing the thruster.

When a suitable location has been selected (section 3.2.1 on page 15) for the thruster proceed with the next steps to cut the opening in the transom.

1. Place the thruster backing plate at the desired location and trace the central opening (see Figure 7 on the next page).
2. Remove the plate and cut the transom in the shape of the trace made in step 1.
3. Note that in the case of cored fibreglass hulls a modification must be made. For hull core materials that are soft and cannot withstand the clamping load of the backing and mounting plates, material must be removed from the core and internal hull so that the backing plate can be mounted directly to the external hull. If it is known that the core is strong and firm enough, then the mounting holes can be drilled directly through the core and internal hull (next step) and the backing plate can be mounted directly to the internal hull. In either case, new fibreglass should be laid down to seal-off any exposed hull core. See Figure 8 on the following page for a depiction of this modification.
4. From outside the vessel, fit the thruster-tube assembly through the newly cut hole and from inside the vessel fit the backing plate over the motor. When the placement is satisfactory, remove the thruster and match drill sixteen 17/32" holes with the existing mounting holes in the backing plate through the hull.




Figure 7 – Backing plate for bolt-on thrusters





Figure 8 – Installation of bolt-on thrusters to cored fiberglass hulls

### 3.2.4 Installing the Thruster to the Transom

This section has been prepared to assist the owner and installer in understanding the installation of transom mounted thrusters. All work should be performed by a professional who is competent in marine mechanical installations.

1. Figure 9 illustrates this step. Carry out a dry installation to ensure that the mounting plates and thruster assembly properly fit together on the transom. The mounting plate is already bolted and sealed to the thruster assembly. From the outside of the hull, fit the motor end of the thruster through the central opening with the mounting plate placed against the transom. Fit the backing plate over the motor from the inside of the hull, sandwiching the transom between the two plates. Fasten this into place with 1/2" fasteners (316 stainless steel is recommended). Once the dry installation has yielded satisfactory results (plate lies flat on transom and there is no interference with other vessel components) remove the thruster from the transom and continue to next step.



*Figure 9 – Thruster fitted onto transom*

2. Repeat step 1, but this time apply 3M™ 5200 (regular or fast cure) marine adhesive sealant between the mounting plate and the vessel's hull, the fasteners used to fasten the thruster to the transom, and the mounting holes. Refer to the instructions provided with the sealant for information regarding gap size limits and cure time. At this point the mechanical installation of the thruster to the vessel can be regarded as complete. Note down the make and model of the hydraulic motor on page 1 of this manual for future reference if you have not done so already.

### 3.3 LUBRICATING OIL SYSTEM

The thruster needs to be connected to a source of oil to provide lubrication to the gears, bearings, and seals. This can be achieved by either connecting the thruster to an elevated header tank (section 3.3.1) or pumping oil through the thruster assembly (section 3.3.2).

#### 3.3.1 Header Tank Location and Oil Fill Instructions

The distance between the bottom of the header tank and the centreline of the thruster should be at least 1.25 times the distance between the *heaviest* water line and the centreline of the thruster (see figure below); this ensures there is positive pressure within the thruster that prevents the ingress of seawater should a seal failure occur. The header tank can be connected to either port A or port B which are defined in the figure below. Continue from step 2 in the instructions in section 4.7.1 on page 25 to complete the oil fill procedure.




Figure 10 – Required elevation of header tank over the waterline

#### 3.3.2 Circulating Oil Method

Instead of connecting the thruster to a header tank it can be connected to a pump that circulates oil through the thruster. This lubrication method is recommended for station-keeping and other severe commercial applications. In this case, port A defined in Figure 10 above should be connected to the lube pump pressure output. Port B on the opposite side of the saddle should be connected to a return line to the lube reservoir. Note that the connections are not interchangeable (i.e. port B must not be connected to the lube pump pressure port). Kobelt manufactures a pump (part number: KP426-B) specifically designed for this application that is available for purchase. Use SAE75W-90 synthetic gear oil.

## 4 MAINTENANCE AND SERVICE

### 4.1 PREVENTATIVE MAINTENANCE

- Header tank level should be checked daily.
- Check amount of material remaining on zinc anode. Anodes with less than 50% of the original material remaining should be replaced. The interval can vary greatly depending on the operating conditions of the vessel. A vessel in warm water that docks in busy marinas can go through an anode in a week while a vessel in cold unoccupied waters might take a couple months before a replacement is required.
- Replace shaft seal as described in section 4.8 on page 26.
  - 5 years for pleasure boats.
  - 2 years for commercial vessels, parking application.
  - 1000 thruster hours for commercial vessels, station-keeping.
- Replace the oil in the vessel as described in section 4.7 on page 25.
  - The lower of 5 years or 2,000 boat hours, pleasure craft.
  - The lower of 2 years of 1,500 boat hours, commercial boats using the thruster for parking only.
  - 500 thruster hours, commercial boats using the thruster for station keeping.

#### NOTICE

It is recommended that any required service work on a Keypower thruster be performed by a qualified individual. Please contact the nearest Kobelt authorized distributor for assistance.

### 4.2 RECOMMENDED SPARE PARTS

As a minimum Kobelt recommends the following spare parts are on-hand:

*Table 4 – Recommended spares*

Quantity	Part Number	Description
1	KP16X-RK	Repair kit
3	KP12-J-003	Zinc anode

For detailed parts lists see section 6 *Parts Lists* of this manual.

### 4.3 PROPELLER INSTALLATION AND REMOVAL

Remove the propeller by following the instructions in Figure 11 below. You will need a 1-7/8" wrench to remove the prop nut and a 3/16" hex key to loosen the set screw.

#### NOTICE

Do not use undue force or blows to the propeller to remove it.





Figure 11 – Propeller removal instructions

To reinstall the propeller replace it on the thruster (ensure the key has not fallen out of the propeller shaft's keyway prior to this). Check for tip clearance by rotating the propeller once and ensuring it does not bind anywhere. Next replace the prop nut and torque it to 60 lbf-ft. Lastly, torque the set screw to 114 lbf-in. Rotate the propeller once more to again ensure clearance between the propeller blades and the tunnel.


## 4.4 BOLT-ON THRUSTER TUBE REMOVAL AND INSTALLATION

The following steps describe how to remove the tube from the thruster assembly:

1. Remove the propeller as described in section 4.3 on page 21.
2. *This step is applicable only if the thruster is already installed to the vessel.* Remove the leg by removing the four hex bolts holding it to the saddle. Do not lose the three O-rings that seal between the saddle and leg. Some oil will dump out of this connection that must be disposed of according to your local environmental regulations.



3. Loosen and remove the six nuts that fix the tube to the thruster assembly.



4. The tube can now be slipped off.

To reinstall the tube:

1. Replace the tube onto the saddle and loosely refasten in six places. The heads of the carriage should be on the inside of the tunnel (see Figure 12 below).
2. *This step does not apply if leg is already installed to the saddle.* Reinstall the leg to the saddle. Do not forget the three O-rings that seal the saddle-leg contact surfaces. Apply silicone sealant to the four fasteners and torque them to 92 lbf-ft.
3. Reinstall the propeller as described in section 4.3 on page 21.
4. With the tube aligned in a position that ensures proper tip clearance, tighten the six fasteners holding the tube to the saddle to 54 lbf-ft.
5. Rotate the propeller once again to ensure propeller clearance.
6. If the leg was uninstalled to allow removal of the tube, then the oil lost must be replaced. See section 4.7 on page 25.




Figure 12 – Tube mounting hardware orientation.

If you are **installing a new tube**, you will have to make a cut out for the thruster leg and drill new holes for the mounting hardware. Follow the instructions in section 3.1.4 *Installing the Thruster to the Tube* starting on page 13 up to and including step 6. Complete the installation by continuing from section 3.2.2. You also will likely have to remove the saddle (see Figure 13 for applicable fasteners) from the mounting plate to re-drill the mounting holes; doing so will break the seal between the saddle and the mounting plate. Remember to clean and reapply 3M 5200 marine adhesive sealant (follow instructions regarding gap size limits and cure time) to the surface between the mounting plate and saddle, and to the fasteners which hold the mounting plate to the saddle. There should be no need to remove the mounting plate from the vessel's hull at any point.




Figure 13 – Fasteners for mounting saddle to mounting plate



## 4.5 SETTING COUPLING DISTANCE

The coupling connecting the motor output shaft and thruster input shaft are already set to the correct positions when you receive your thruster, however, if ever during the life of your thruster you must remove the coupling from either of the shafts you must reinstall the coupling correctly. Complete the following steps:

1. Make sure that there is a  $\frac{1}{16}$ " clearance between the spider pins and the coupling jaws (shown in Figure 14 below).
2. Torque the set screws to 23 lbf-ft.




Figure 14 – Jaw coupling installation

## 4.6 BEARING CAP REMOVAL & OIL DRAIN

The instructions below describe how the bearing cap is removed. Note that doing this requires you to replenish the oil that is lost during the procedure.

1. If connected to an oil circulation system, make sure the lube pump is off before commencing any work.
2. Remove the propeller (see section 4.3 *Propeller Installation and Removal* on page 21).
3. Remove the anode by loosening and removing the two screws that hold it to bearing cap.
4. Remove the two socket head screws from the bearing cap.
5. Slowly pull the bearing cap and shaft assembly out. Oil will flow out. Also retain any shims that come out. Dispose of the oil in accordance with your local environmental regulations.
6. It is recommended to use this as an opportunity to inspect the gears, bearings, and seals.
7. Complete any tasks you intended on doing (e.g. replacing the shaft seals).
8. Reinstall in this order:
  - a. Any shims that came out.
  - b. The shaft sub assembly.
  - c. The bearing cap and its screws (torque to 33 lbf-ft).
  - d. The anode and its screws (torque to 92 lbf-in)
  - e. Propeller (see section 4.3 on page 21 for instructions).
9. *This step is applicable to thrusters that are lubricated via header tank (not via circulating oil).* Continue from step 2 in the instructions in section 4.7.1 on page 25 to refill the oil in the thruster.

## 4.7 OIL CHANGES

### NOTICE


Dispose of any old/excess oil in accordance with your local environmental regulations.

#### 4.7.1 Header Tank Fill Method

1. *This step should be skipped for first-time thruster installation.* Remove the bearing cap from the thruster (instructions are in section 4.6 on page 24) and allow the oil to drain. Reinstall the bearing cap.
2. Remove the 1/4" NPT plug in the port opposite of the one which the header tank is connected to. This will be you oil level indicator port.
3. Fill the header tank with SAE75W-90 synthetic gear oil. Fill until oil starts coming out of the oil indicator port then reinstall the plug removed in the previous step.
4. Continue filling the header tank until it is two thirds full, then replace its cap.

#### 4.7.2 Pump Out Method


This method allows for replacing the oil without removing the bearing cap and without taking the boat out of the water. This method can be used when it is not necessary to replace the shaft seal. The instructions refer to ports A & B which are defined below.



1. Disconnect the header tank from the thruster and remove the plug from the port opposite of the port that the header tank was connected to (ports A & B).
2. Connect port A to a manual pump and connect port B to some sort of receptacle that will allow you to collect and examine the oil.
3. Pump SAE75W-90 oil into the thruster until clean oil starts coming out of port B.
4. Reinstall the plug and header tanks which were removed in previous steps.
5. Fill the header tank it until it's two thirds full and replace its cap.

## 4.8 SHAFT SEAL REPLACEMENT

Removing the shaft seal requires removing the bearing cap for which instructions can be found in section 4.6 on page 24. When replacing the shaft seals of the thruster you must orient them face-to-face and you must replace the spring on the outer shaft seal with a -028 O-ring (see Figure 15 below). All the required components are included in repair kit KP16X-RK.



*Figure 15 – Shaft seal replacement details*

## 5 HYDRAULICS



Observe the following precautions:

- Wear safety goggles.
- Exhaust all pressure prior to working on hydraulics.
- Never run your hand along pressurized lines to look for a leak.
- If you are unsure of any of the instructions or unqualified to work on hydraulics you should consult with an expert.
- A method of pressure regulation must be implemented in the hydraulic system.

A hydraulic injection injury can result in an amputation of a limb or death, be careful!

Hydraulic systems can vary greatly depending on the thruster installation (the thruster size itself, quantity of thrusters, and the displacement of the motor you receive) and other parameters of the vessel (whether other hydraulic machinery is also present). For this reason, it is impossible to provide a general hydraulic schematic for Keypower thruster systems. Kobelt or your nearest distributor can design and provide a hydraulic system (e.g. pumps and valves) for your application. An application data sheet can be found on [our website](#) and should be submitted to [sales@kobelt.com](mailto:sales@kobelt.com).

*Page Intentionally Left Blank*

# 6 PARTS LISTS

## 6.1 TUNNEL THRUSTER TOP-LEVEL ASSEMBLY




Figure 16 – KP16 & KP18 hydraulic tunnel thrusters’ parts list diagram

Table 5 – KP16 & KP18 hydraulic tunnel thrusters' parts lists

Item	KP16A-HD-H-TH Qty.	KP16A-H-TH Qty.	KP16B-HD-H-TH Qty.	KP16B-H-TH Qty.	KP18A-HD-H-TH Qty.	KP18A-H-TH Qty.	KP18B-HD-H-TH Qty.	KP18B-H-TH Qty.	Part Number	Description	Notes (page 42)
1	1	-	-	-	-	-	-	-	KP16A-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
1	-	1	-	-	-	-	-	-	KP16A-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
1	-	-	1	-	-	-	-	-	KP16B-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
1	-	-	-	1	-	-	-	-	KP16B-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
1	-	-	-	-	1	-	-	-	KP18A-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
1	-	-	-	-	-	1	-	-	KP18A-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
1	-	-	-	-	-	-	1	-	KP18B-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
1	-	-	-	-	-	-	-	1	KP18B-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
2	1	1	-	-	-	-	-	-	KP10-H-011-AN	Propeller	3
2	-	-	1	1	-	-	-	-	KP10-H-012	Propeller	3
2	-	-	-	-	1	1	-	-	KP10-H-013-AN	Propeller	3
2	-	-	-	-	-	-	1	1	KP10-I-014	Propeller	3
3	1	1	-	-	1	1	-	-	KP11-J-005-AN	Prop nut	3
3	-	-	1	1	-	-	1	1	KP11-J-006	Prop nut	3
4	1	1	-	-	-	-	-	-	KP19-H-011-AN	Saddle	4, 5, 7, 6, 26
4	-	-	1	1	-	-	-	-	KP19-H-012	Saddle	4, 5, 7, 6, 26
4	-	-	-	-	1	1	-	-	KP19-H-013-AN	Saddle	4, 5, 7, 6, 26
4	-	-	-	-	-	-	1	1	KP19-I-014	Saddle	4, 5, 7, 6, 26

Parts above vary depending on thruster configuration.

Continued on next page...

Continued from previous page...

Parts below are common to all KP16 & KP18 tunnel thrusters.

Item	Qty	Part Number	Description	Notes (p. 42)
5	3	KP36-A-002	1/4 NPT plug, SS	26
6	4	1001-1624	Bolt, hex, 5/8"-11 X 1-1/2", F593C	5
7	2	1001-1424	Bolt, hex, 1/2-13 X 1-1/2", F593C	6
8	1	1016-1208	Set screw, cup point, 3/8"-16 X 1/2", 18-8 SS	3
9	6	1022-0114	Nut, hex, 1/2"-13, F594C	7
10	4	1023-0243	Washer, flat, 5/8", 18-8 SS	5
11	8	1023-0114	Washer, flat, 1/2", 18-8 SS	7
12	4	1023-0316	Lock washer, split, medium, 5/8", 18-8 SS	5
13	8	1023-0314	Lock washer, split, medium, 1/2", 18-8 SS	7
14	6	KP20-A-028	Carriage bolt, 1/2"-13 X 1-3/4", 18-8 SS	7
15	1	1305-5562-BE	Key, 3/8" square X 3-7/8" long, form B, 316 SS	3
16	1	1305-5324-D	Key, 1/4" square X 1-1/2" long, form A, 1018	9
17	1	KP44-J-010	Coupling spider	9
18	1	KP44-J-011	Coupling hub	9
19	1	KP44-J-012	Coupling hub	9
20	2	1101-0009	O-ring, -009, NBR 70D	25
21	2	KP31-J-006	O-ring, -155, NBR 70D	25
22	1	-	Motor	1, 6, 9



*Page Intentionally Left Blank*

6.2 BOLT-ON THRUSTER TOP-LEVEL ASSEMBLY




Figure 17 – KP16 & KP18 hydraulic bolt-on thrusters' parts list diagram

Table 6 – KP16 & KP18 hydraulic bolt-on thrusters' parts lists

Item		KP16A-HD-ST Qty.	KP16A-H-ST Qty.	KP16B-HD-ST Qty.	KP16B-H-ST Qty.	KP18A-HD-ST Qty.	KP18A-H-ST Qty.	KP18B-HD-ST Qty.	KP18B-H-ST Qty.	Part Number	Description	Notes (page 42)
1	1	1	1	1	1	-	-	-	-	.TUBE-FG-1603	Thruster tube	11
1	-	-	-	-	-	1	1	1	1	.TUBE-FG-1803	Thruster tube	11
2	1	1	1	-	-	-	-	-	-	KP10-H-011-AN	Propeller	3
2	-	-	1	1	1	-	-	-	-	KP10-H-012	Propeller	3
2	-	-	-	-	-	1	1	-	-	KP10-H-013-AN	Propeller	3
2	-	-	-	-	-	-	-	1	1	KP10-I-014	Propeller	3
3	1	1	-	-	-	1	1	-	-	KP11-I-005-AN	Prop nut	3
3	-	-	1	1	1	-	-	1	1	KP11-I-006	Prop nut	3
4	1	-	-	-	-	-	-	-	-	KP16A-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
4	-	1	-	-	-	-	-	-	-	KP16A-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
4	-	-	1	-	-	-	-	-	-	KP16B-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
4	-	-	-	-	1	-	-	-	-	KP16B-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
4	-	-	-	-	-	1	-	-	-	KP18A-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
4	-	-	-	-	-	-	1	-	-	KP18A-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
4	-	-	-	-	-	-	-	1	-	KP18B-LEG-HD	Leg subassembly	2, 3, 5, 9, 26
4	-	-	-	-	-	-	-	-	1	KP18B-LEG_ASSY	Leg subassembly	2, 3, 5, 9, 26
5	1	1	-	-	-	-	-	-	-	KP19-H-011-S	Saddle	5, 6, 8, 10, 11, 26
5	-	-	1	1	1	-	-	-	-	KP19-H-012-S	Saddle	5, 6, 8, 10, 11, 26
5	-	-	-	-	-	1	1	-	-	KP19-H-013-S	Saddle	5, 6, 8, 10, 11, 26
5	-	-	-	-	-	-	-	1	1	KP19-I-014-S	Saddle	5, 6, 8, 10, 11, 26

Parts above vary depending on the thruster configuration.

Continued on next page...

Continued from previous page...

Parts below are common to all KP16 & KP18 bolt-on thrusters.

Item	Qty	Part Number	Description	Notes (p. 42)
6	1	KP35-H-001	Mounting plate	10, 13
7	1	1305-5324-D	Key, 1/4" square X 1-1/2" long, form A, 1018	9
8	1	1305-5562-BE	Key, 3/8" square X 3-7/8" long, form B, 316 SS	3
9	1	KP44-J-011	Coupling hub	9
10	1	KP44-J-012	Coupling hub	9
11	1	KP44-J-010	Coupling spider	9
12	2	1001-1424	Bolt, hex, 1/2-13 X 1-1/2", F593C	6
13	4	1001-1628	Bolt, hex, 5/8"-11 X 1-3/4", F593C	5
14	2	1002-1210-L	Bolt, low socket, 3/8"-16 X 5/8", 18-8 SS	12
15	1	1016-1208	Set screw, cup point, 3/8"-16 X 1/2", 18-8 SS	3
16	6	1022-0114	Nut, hex, 1/2"-13, F594C	8
17	8	1023-0114	Washer, flat, 1/2", 18-8 SS	8
18	4	1023-0243	Washer, flat, 5/8", 18-8 SS	5
19	8	1023-0314	Lock washer, split, medium, 1/2", 18-8 SS	8
20	4	1023-0316	Lock washer, split, medium, 5/8", 18-8 SS	5
21	6	KP20-A-028	Carriage bolt, 1/2"-13 X 1-3/4", 18-8 SS	8
22	2	1101-0009	O-ring, -009, NBR 70D	25
23	2	KP31-J-006	O-ring, -155, NBR 70D	25
24	3	KP36-A-002	1/4 NPT plug, SS	26
25	1	-	Motor	1, 6, 9
26	1	KP35-H-002	Backing plate	-

\*Item 26 not shown in parts list diagram (Figure 17).

*Page Intentionally Left Blank*

6.3 LEG SUBASSEMBLY




Figure 18 – KP16 & KP18 leg subassemblies’ parts list diagram

Table 7 – KP16 & KP18 leg subassemblies' parts lists

								Notes (page 42)
Item		Part Number		Description				
1	1	1	-	-	-	KP13-H-008	Pinion shaft	15
1	-	-	1	1	-	KP13-I-009	Pinion shaft	15
1	-	-	-	-	1	KP13-H-018	Pinion shaft	15
1	-	-	-	-	-	KP13-I-019	Pinion shaft	15
2	1	1	1	1	-	KP13-S16-SUB	Shaft subassembly	16
2	-	-	-	1	1	KP13-S18-SUB	Shaft subassembly	16
3	1	-	1	-	1	KP15-J-005-AN	Bearing cap	15
3	-	1	-	1	-	KP15-J-006	Bearing cap	15
4	1	-	-	1	-	KP17-H-011-AN	Leg	15
4	-	1	-	-	1	KP17-H-012	Leg	15
4	-	-	1	-	-	KP17-H-013-AN	Leg	15
4	-	-	-	-	1	KP17-I-014	Leg	15

Parts above vary depending on the thruster leg configuration.

Continued on next page...

Continued from previous page...

Parts below are common to all KP16 & KP18 thruster legs.

Item	Qty	Part Number	Description	Notes (p. 42)
5	1	KP12-J-003	Zinc	-
6	1	KP18-J-004	Retainer ring	-
7	1	KP18-J-009	Spacer ring	-
8	1	1305-5324-D	Key, 1/4" square X 1-1/2" long, form A, 1018	-
9	1	KP33-J-023	Bearing lock nut, N05	21
10	1	KP33-J-024	Bearing lock washer, W05	21
11	1	KP33-J-025	Bearing	-
12	1	KP33-J-026	Bearing	-
13	5	1001-1112	Bolt, hex, 5/16"-18 X 3/4", F593C	18
14	6	1001-1212	Bolt, hex, 3/8"-16 X 3/4", F593C	19
15	2	1002-1120	Bolt, socket head, 5/16"-18 X 1-1/4", F837 CW	20
16	2	1002-1424	Bolt, socket head, 1/2"-13 X 1-1/2", F837 CW	17
17	5	1023-0311	Lock washer, split, medium, 5/16", 18-8 SS	18
18	6	1023-0312	Lock washer, split, medium, 3/8", 18-8 SS	19
19	1	KP43-J-003	Lock nut, top lock, 5/8"-11, grade C	-
20	1	1101-0028	O-ring, -028, NBR 70D	23, 25
21	1	1101-0244	O-ring, -244, NBR 70D	25
22	1	7039-0671	1/8 NPT plug, SS	22
23	2	KP22-J-004	Shaft seal	23, 25

Also see note 14 on page 42 which is applicable to the entire leg assembly.



6.4 SHAFT SUBASSEMBLY




Figure 19 - Shaft subassembly parts list diagram

Table 8 – Shaft subassembly parts list

Item	KP13-S16-SUB Qty.	KP13-S18-SUB Qty.	Part Number	Description	Notes (page 42)
1	1	1	KP13-J-010	Propeller shaft	-
2	1	-	KP14-J-005	Gear set	15
2	-	1	KP14-J-006	Gear set	15
3	1	1	KP16-J-002	Bearing spacer	15
4	1	1	KP18-J-010	Bearing retainer	-
5	1	1	1305-5520-D	Key, 3/8" sqr. X 1-1/4" long, form A, 1018	-
6	1	1	KP33-G-016	Bearing	-
7	1	1	KP33-J-029	Bearing lock nut, N08	24
8	1	1	KP33-J-030	Bearing lock washer, W08	24
9	1	1	KP33-J-031	Bearing	15

6.5 ACCESSORIES




Figure 20 - Other KP thruster components

Table 9 – Accessory parts

Item	Qty	Part Number	Description
1	1	1041-002430	Puller tool*
2	1	KP-30114	Header tank
3	1	KP-30117	Header tank mounting bracket
4	1	KP-30123	Hose clamp

\*The puller tool is simply a 1-1/2”-6 UNC X 3” long hex bolt.

## 6.6 PARTS LISTS NOTES

1. Note that the motor is not standard across thruster installations and is typically selected to best fit your existing hydraulic system. Therefore, there is no standard part number for ordering a motor replacement. If a replacement motor is needed, read the manufacturer and part number information on the motor and provide it to your nearest authorized Kobelt distributor for further assistance. Additionally, you may have already noted the motor make and model on page 1 of this manual.
2. Leg assembly parts lists are on page 37.
3. See section 4.3 on page 21 for propeller removal and installation instructions.
4. For tunnel thrusters, saddle reinstallation requires resealing the saddle to the tube (section 3.1.4 on page 13) and may require resetting the coupling distance (section 4.5 on page 24). Note that the tunnel mounting holes may need some modifying as well.
5. Apply silicone sealant to the fasteners that mount the leg to the saddle and torque them to 92 lbf-ft.
6. Torque the fasteners that mount the motor to the saddle to 54 lbf-ft.
7. Apply 3M 5200 marine adhesive sealant to the fasteners that mount the saddle to the tube and torque them to 46 lbf-ft. Observe any requirements regarding gap sizes and cure time.
8. Torque the fasteners that mount the saddle to the tube to 54 lbf-ft.
9. See section 4.5 on page 24 for instructions for setting coupling distance.
10. Clean contact surfaces between saddle and mounting plate and reapply 3M 5200 sealant. Observe any requirements regarding gap sizes and cure time. The mounting holes in thruster tube might also need modifying.
11. See section 4.4 on page 22 for instructions of how to remove and install the tube.
12. Apply 3M 5200 marine sealant and torque to 9 lbf-ft. Observe any requirements regarding gap sizes and cure time.
13. Replacing the mounting plate requires resealing the surface between the plate and the hull of the vessel and the fasteners holding them together with 3M 5200 marine adhesive sealant. Observe any requirements regarding gap sizes and cure time.
14. When taking apart the leg assembly be careful to not lose any shims you may find and do not forget to reinstall them when putting the unit back together. Failure to do so can cause the gears to mesh improperly reducing their life. Additionally, note 26 is applicable when replacing the leg assembly or any of its components.
15. Replacing this part requires re-shimming of the gear set. Please consult your nearest authorised Kobelt representative for further assistance.
16. If replacing the entire shaft subassembly then note 15 above applies. For individual parts see shaft subassembly's parts list on page 40.
17. Torque to 33 lbf-ft.
18. Torque to 128 lbf-in.
19. Torque to 19 lbf-ft.
20. Torque to 92 lbf-in.
21. Lock nut is 1.57"/40mm in diameter and requires hook-type spanner wrench to tighten. Bend lock washer tab into lock nut slot after tightening the lock nut.
22. Apply Loctite 243 to threads.
23. Outer most shaft seal's spring gets replaced by an O-ring (see section 4.8 on page 26 for detailed instructions). All are provided in the repair kit.

24. Lock nut is 2.26"/57mm in diameter and requires hook-type spanner wrench to tighten. Bend lock washer tab into lock nut slot after tightening the lock nut.
25. Part is included in repair kit that can be purchased from your authorized Kobelt distributor. Repair kit part number is KP16X-RK.
26. Uninstalling/replacing/modifying this part may cause a loss of lubricating oil which must be disposed of in accordance with your local environmental regulations. Additionally, the oil must be replaced as per instructions in section 4.7 on page 25 prior to using the thruster.

7 TECHNICAL DRAWINGS

7.1 TUNNEL THRUSTERS




Figure 21 – KP16 & KP18 tunnel thruster dimensions

7.2 BOLT-ON THRUSTERS




Figure 22 – KP16 & KP18 bolt-on thruster dimensions

**Note:** Figure depicts standard tube offering. If it is incompatible with your vessel, please contact Kobelt Manufacturing and we can try to come up with a custom solution for you.

---

## 8 WARRANTY

---

Kobelt Manufacturing Co. Ltd. ("Kobelt") warrants the Products and Parts manufactured by Kobelt to be free from defects in workmanship or material and that said products are designed mechanically and functionally to perform to specifications.

This warranty is effective providing:

- The equipment is used within the intended operating conditions and in accordance with Kobelt recommendations
- The equipment is installed according to equipment diagrams, specifications and recommendations which Kobelt has provided

This warranty becomes invalid if the factory supplied serial number has been removed or altered on the product. This warranty does not cover cosmetic damage or damage caused by an act of God, accident, misuse, abuse, negligence or modification of any part of the product. This warranty does not cover damage due to improper operation or maintenance, connection to inappropriate equipment or attempted repair by anyone other than an authorized Kobelt representative.

Upon identification of a potential issue or defect with a Kobelt Product or Part, the Warranty Applicant ("Applicant") must immediately contact Kobelt and describe the issue in writing, by letter, fax, email or other electronic conveyance. Kobelt will then assess the cause of the defect and determine warranty applicability and appropriate remediation.

If any part is found to be defective, Kobelt will replace said part FOB the Kobelt factory provided that any such defective part is returned by the Buyer with freight and applicable forwarding charges prepaid by the Buyer. Kobelt's sole obligation to the Applicant will be to repair or replace the defective part with same or similar product, to a maximum value of the list price of the product or part. The Kobelt warranty does not cover labour charges, travel or any other associated expenses.

All Products and Parts manufactured by Kobelt, with the exception of brake discs and pads, are subject to a warranty against manufacturer's defects in materials or workmanship for a period of two (2) years from the date of purchase. Thrusters and brake discs are subject to a one (1) year warranty period, and brake pads and linings are not covered by warranty.

Kobelt will be responsible for all Products or Parts sold by Kobelt but manufactured by 3<sup>rd</sup> party manufacturing companies. However, these products and parts are subject to applicable 3<sup>rd</sup> party warranties and may not be the same as the Kobelt warranty.



**Kobelt Manufacturing Co. Ltd.**

8238 129th Street  
Surrey, British Columbia,  
Canada, V3W 0A6

Sales Tel: +1-604-572-3935

Fax: +1-604-590-8313

Email: [sales@kobelt.com](mailto:sales@kobelt.com)

Website: [www.kobelt.com](http://www.kobelt.com)

Made in Canada / Printed in Canada